

EC5500R
Digital Indicating Controller
Instruction Manual

Ohkura

WXPEC5500R01E






Oct. 2006 (2nd edition)


All Rights Reserved, Copyright © 2006, Ohkura Electric Co., Ltd.

For Safety Using

Thank you for purchasing our EC5500R Digital Indicating Controller. For proper and effective use of full functions of this instrument, please read and understand this instruction manual well before use.

The following symbol marks are used in this instrument and the instruction manual for safety using.

Safety Precautions	
 Warning	It is clearly described when dangerous situation for causing death or serious injury of the user is expected in case of mishandling.
 Caution	It is clearly described when dangerous situation for causing light injury of the user or object damage is expected in case of mishandling.
	Indicate "Caution in handling." It is described at points where the instruction manual needs to be referred for protection of the user and equipment.
	Indicate "Protective grounding terminal." Be sure to provide grounding before operating the instrument.
	Indicate "Caution for electric shock." It is described at points where electric shock may occur if instruction is neglected.

To ensure safety in handling the instrument, please be sure to observe the following warnings/cautions as well as the precautions in this manual.	
 Warning	
General	To prevent an electric shock, be sure to disconnect this instrument from the main power supply when wiring it.
Protective grounding	(1) To prevent an electric shock, be sure to provide protective grounding before providing power supply to this instrument. (2) Do not cut off the protective grounding conductor or disconnect protective grounding.
Power supply	Check that the power supply voltage of this instrument matches that of the supply source.
Environment	Do not operate this instrument in atmosphere containing inflammable, explosive or corrosive gas, or in environments where water or steam may be splashed on the product.
Input/output wiring	To prevent electric shock, be sure to provide wiring after turning off the power.

<div>⚠</div> <div>Caution</div>	
Input/output wiring	Do not use the open terminals for other purposes such as relay.
Inside of instrument	Do not disassemble the inside of the main unit.
[Caution]	
Instruction manual	<p>(1) Please deliver this instruction manual to the final user.</p> <p>(2) Be sure to read this instruction manual before handling the instrument.</p> <p>(3) If you find any questions, errors or omissions, please inform our sales representative.</p> <p>(4) When you have read this instruction manual, store it safely near the instrument.</p> <p>(5) If it is lost, stained or damaged by accident, please inform our dealer where you purchased the instrument or our sales representative.</p> <p>(6) It is forbidden to reprint or copy all or part of this instruction manual without permission.</p>
Maintenance	It is prohibited to remove or disassemble the unit, printed circuit board, etc. by anyone except our serviceman or persons with our approval.
Disposal	To dispose of this instrument, consign to the special agent as an industrial waste.
Cleaning	<p>(1) Clean the surface of this instrument with a dry cloth.</p> <p>(2) Do not use organic solvents.</p> <p>(3) Cleaning the instrument after turning off the power.</p>
Revisions	This instruction manual may be revised without prior notice.

How to Use This Instruction Manual

This instruction manual consists of “For safety using”, “Table of Contents,” and “Chapters 1 to 10” as follows. Read the applicable pages to suit your purpose:

Chapter and title	At purchase and installation	In daily operation	In maintenance and troubleshooting
For safety using (pages 1 and 2)	◎	◎	◎
Chapter 1 When Instrument Arrives	◎		
Chapter 2 Installation	◎		○
Chapter 3 Wiring	◎		○
Chapter 4 Part Names	○	○	
Chapter 5 Basic Operation and Setting	○	○	
Chapter 6 Operation Guidance		○	
Chapter 7 List of Items		○	
Chapter 8 Operation		○	
Chapter 9 Procedure for Major Functions		○	
Chapter 10 Troubleshooting			◎

◎: Be sure to read the chapter ○: Read if necessary.

Type of Instruction Manual

This manual ➡		Name	Description
	1	EC5500R Digital Indicating Controller Instruction Manual WXPEC5500R01E	Describes the general information on EC5500R including installation, wiring, operation and functions.
	2	RS-232C/RS-422A/RS-485 Interface Instruction Manual WXPEC5500R02E	Describes the setup, communication protocol, etc. for using communication.
	3	AO, Isolated Remote SP Instruction Manual WXPEC5500R03E	Describes AO, isolated remote SP wiring, setup and functions.
	4	Expansion Interface, Servo Drive Output Instruction Manual WXPEC5500R04E	Describes servo drive and expansion interface wiring, setup and functions.

This instruction manual describes the cautioning and reference information with the following marks:


Caution/reference mark	
[Caution]	This is cautionary information for correct use of the instrument. Be certain to read.
[Reference]	This is information to help you use the functions of this instrument more effectively.
	There is an item, table, figure or another instruction manual to be referred at the same time.

Table of Contents


Chapter 1		Chapter 8 Operation	38
When Instrument Arrives.....	5	8.1 Control Method.....	38
1.1 Checking the Accessories	5	8.2 Automatic Control (AUTO)	
1.2 Checking the Specifications	5	and Manual Control (MAN)	38
1.3 Display.....	6	8.2.1 SP/Output Display Switching..	38
Chapter 2 Installation.....	7	8.2.2 AUTO/MAN Switching	39
Chapter 3 Wiring.....	9	8.2.3 Setting Output Value at MAN ..	39
Chapter 4 Part Names	12	8.3 SP	40
Chapter 5 Basic Operation		8.3.1 Normal SP and Multi-SP	40
and Setting	13	8.3.2 Multi-SP Setting, Switching	
5.1 Screen Types	13	and Ramping	40
5.2 Selection of Group/Item on		8.3.3 PV Start.....	41
Screen	14	8.3.4 Anti-overshoot	41
5.3 Data Setting Procedure	15	8.4 Automatic Tuning.....	41
5.3.1 Numerical Data	15	8.5 Self Tuning.....	41
5.3.2 Character Data	15	8.6 Selection of Operation Method ..	43
5.4 System Setup	16	8.7 Power Failure and Power	
5.5 All Reset	17	Restoration during Operation.....	44
5.6 Setting Items of Each Function	18	Chapter 9 Procedure	
5.6.1 Setting up the Controlled		for Major Functions.....	45
SP Each Time	18	9.1 Alarms.....	45
5.6.2 Switching SP registered		9.1.1 Pause Alarms	45
beforehand	18	9.1.2 Hysteresis Width	45
5.6.3 Use of Alarms	19	9.1.3 ON Delay Type.....	46
5.6.4 Gapped Control		9.2 Output Limit.....	46
(Nonlinear Control)	20	9.3 Input Functions	46
5.6.5 Remote SP	20	9.3.1 Scaling	46
5.6.6 Profiling Control	20	9.3.2 Square root	47
5.7 Key Lock.....	21	9.3.3 Sensor Correction	47
Chapter 6		9.4 Control RUN/STOP.....	47
Operation Guidance	22	9.5 ON-OFF Control Hysteresis	
6.1 Operation Screen	23	Width	47
6.2 Parameter Screen	25	9.6 Profiling Control	48
6.3 Setup Screen.....	27	9.7 Gapped Control	
Chapter 7 List of Items.....	31	(Nonlinear Control).....	49
7.1 Operation Screen	31	9.8 Heat/Cool Control	49
7.2 Parameter Screen	32	Chapter 10 Troubleshooting.....	51
7.3 Setup Screen.....	33		

Chapter 1 When Instrument Arrives


1.1 Checking the Accessories

When this instrument arrives, please check on the accessories and appearance and check that there is no lacking parts or damages. If you find any inappropriate parts, inform our dealer where you purchased the instrument or our sales representative.

This instrument has the following accessories:



Mounting fixture (2)




Instruction manual
(this document)



Unit seal (separately sold)

1.2 Checking the Specifications



[Caution]

When the number of contact output points are two (standard), contacts DO3 and DO4 are not output. However, the functions are available and similar setup to DO1 and 2 is possible. The condition can be checked by alarm/event display lamp.

ARCNET® is a registered trademark of the U.S. DATAPOINT.

* Designating 1st output, 2nd output and servo drive.

Output type	1st output	2nd output
Single output multi	8	0
Single output 0 to 5mA	6	0
Dual output (Heat/Cool Control)	One of 1,2,5 and 6	One of 1,2,5 and 6
Servo drive	8	0

1.3 Display

[Reference] Display character correspondence table

The display characters used in this instrument and the alphabets indicated by them are shown in table below:


Display character	A	b	C	d	E	F	G	H	I	J	K	L
Alphabet	A	B	C	D	E	F	G	H	I	J	K	L
Display character	M	N	O	P	Q	R	S	T	U	V	W	Y
Alphabet	M	N	O	P	Q	R	S	T	U	V	W	Y

[Reference] Protective sheet

Protective sheet is attached on the front face of this instrument for surface protection. It will use the instrument, remove this sheet.

Chapter 2 Installation

Install this product by establishing holes according to the panel cutout drawing and fixing it with the accessory fixtures. (Unit: mm)



Caution

Mounting procedure

- Fix with the fixture tightening torque of 15N·cm or smaller.
- Attach horizontally and upward angle or 30 degrees or smaller and no downward angle.




Caution

Location

Install at locations with stable peripheral temperature in the range of -10 to 55°C. Avoid the following location:

- Locations where people can touch the terminal easily
- Locations with dusts in the air, with corrosive gas
- Locations with vibration or impact or strong noise
- Locations with direct sunlight or wind and rain (water is splashed)
- Locations with direct wind on the back terminal
- Locations near flammable objects

Outside dimension diagram




Separately sold
part number

	RS-232C	RS-422A	RS-485
*1 Communication module	ZE7101A0110	ZE7101B0408	
*2 Communication cable	HMSU2255B02	WMSU0075A01	WMSU0075A02

*3 DI cable HMSU2695A01:1m
HMSU2695A02:5m

Outside dimension diagram for
Multi-setpoint selector

Multi-setpoint selector
panel cutout





Chapter 3 Wiring

Warning

- Never touch the power supply terminal while the power is supplied. When the power supply terminal is touched, it gets an electric shock.
- Never touch relay output terminal and alarm output terminal when they are connected with power supply.

Caution


- Use a M3.5 press-fitting terminal.
- Use shielded wire and set the signal line (input, AO, communication, etc.) as far away as possible from the power line.
- Use the specified compensating lead wire for thermocouple input.
- Lifetime may be shortened if frequently operated for relay contact output. Use auxiliary relay.
- Attach circuit breaker, switch, etc. on power supply wiring for safety and specify that this is a switch for turning off the power for this instrument.




○ mark indicates ON (short circuit between COM-applicable terminal) and blank indicates OFF (open). Do not use terminal B.


Relation between terminal No. and DI No.


DI No.	1	2	3	4
Terminal No.	1	2	4	8

Connection with exclusive multi-setpoint selector  (page 11)




	Output	Single output	Dual output	
			1st output	2nd output
Connection	Current			
	SSR drive			
	Relay			
Load condition		Current	4 to 20mA DC : Max. 600Ω , 0 to 5mA DC : Max. 2kΩ	
		SSR drive	0 / 15V DC Max.20mA	
		Relay	250V AC 3A Max. (resistive load)	






Expansion I/F




Servo drive



Expansion I/F, servo drive

👉 Expansion Interface, Servo Drive Output Instruction Manual
WXPEC5500R04E


Chapter 4 Part Names



No.	Key/ dial	Function	Chapter/section for reference
①	→	Switch the screen (Operation, Parameter or Setup) and the group on each screen.	Sec. 5.1, 5.2, Chapter 6
②	MAN	Switch SP/output display and automatic (AUTO)/manual (MAN) operation.	Sec. 8.1, 8.2
③	◀	Give data change permission and move the digit for data change.	Sec. 5.3
④	ENT	Switch the display item within a group and register the data.	Sec. 5.2, 5.3, Chapter 6
⑤	◌	Switch the groups on group display of Parameter screen and Setup screen and change the data.	Sec. 5.2, 5.3, Chapter 6
No.	Display	Function	Reference
①	Upper	Display the PV(process variable) or characters that indicate the item name.	Chapter 6, 7
②	Lower	Display SP(setpoint) or various data (numeric values or characters).	Chapter 7
③	SP No.	Used only on Operation screen. Display multi-SP No. (at SP display), output No. (at output display) or the characters that indicate item.	Chapter 6, 7
No.	Lamp	Function	Reference
①	ALM 1-4	Blink during alarm occurrence or when the function assigned to each of DO1 to 4 is executed.	Sec. 5.6.3, 9.1
②	OUT	Light up at the brightness depending on the output value. The light goes off at output = 0%.	—
③	MAN	Light up at MAN (manual control). Blink while the → key is pressed at screen switching or during AUTO/MAN switching standby when the MAN key is pressed.	Sec. 8.1, 8.2
④	TUNE	Blink during automatic tuning and light up during Self tuning.	Sec. 8.4, 8.5
⑤	REM	Light up at communication remote or SP remote.	Sec. 8.6

Chapter 5 Basic Operation and Setting

5.1 Screen Type



Screen name	Description
Operation screen	This is the screen for indicating/setting of PV, SP, output value, Tuning and normal PID necessary for operation.
Parameter screen	This is the screen for setting/confirming the parameters including the multi-PID and alarm for operation.
Setup screen	This is the screen mainly for determining the system functions such as input type and control method.

[Reference]

Relationship between the operation of each screen and displayed information is shown in Chapter 6 "Operation Guidance." In addition, detailed information, setting range and initial value (factory setting) for each item is shown in Chapter 7 "List of Items."

☞ [Reference] What is normal display?

PV (upper display) and SP (lower display) are displayed at AUTO operation, PV and output value (lower display) are displayed at MAN operation. Normal display is displayed at turning on the power, auto restoration, returning from Parameter or Setup screen to Operation screen.

☞ [Reference] What is Auto restoration?

It is the function to return to normal display when no key or dial operation is made for more than 1 minute.

[Reference] If you are lost on which screen it is,



Press the (→) key several times. The screen can be distinguished by the information on the upper display.

PA n (n is a numeric value) ... Parameter screen
SU n (n is a numeric value) ... Setup screen




5.2 Selection of Group/Item on Screen

[Reference]What is a group?


There are several “groups” classifying the items by kind on each screen. Each group is given with a name that indicates the kind. Group name is displayed on the upper display (except for SP or output display) on Operation screen and on lower display in group display on Parameter screen and Setup screen.

Select the item (use  key) after group selection (use  key or dial).


[Reference]

When group display of Parameter screen (upper display is **PA** n (n is a group number of 1 to 13) or **rEt**) or Setup screen (upper display is **SU** n: (n is a group number of 1 to 13) or **rEt**) is displayed, the group can be changed by the dial as well. When the dial is turned clockwise, the group changes in the same direction as the  key, and in the opposite direction as the  key when it is turned counterclockwise. Pressing the  key when the item in a group is displayed will switch the display to the next group number.


Group display on Operation screen



Group display on Parameter screen



Group display on Setup screen



[Caution]

It is only for group display on Parameter screen or Setup screen where the group can be selected with the dial. Please note that turning the dial in other displays will enable setting.

5.3 Data Setting Procedure





Data is classified as “numerical data” and “character data.” Numeric value blinks when change is enabled for numerical data, and the decimal point blinks for character data. It is set up by the following procedure:

[Caution]

If there is no key or dial operation for more than 10 seconds while change is enabled, the value being changed is invalidated (original value is recovered) and change is disabled.




5.3.1 Numerical Data

Change in SP is shown as an example.

- ①  The lowest numeric value blinks when the ◀ key is pressed or dial is turned by 1 click, indicating that change is enabled. Blinks
- ②  The digit to be changed is selected by pressing the ◀ key. Every time the ◀ key is pressed, blinking value moves in order indicated by the arrow in figure on the left. The blinking digit is subject for change. However, value of other digit may be changed as well if there is carrying/borrowing. Blinks
- ③  The value of the subject digit to be changed is changed by turning the dial. The desired value is set using the ◀ key or dial. Blinks
- ④  The value is registered by pressing the ENT key. The value blinking stops and the display returns to usual display.

5.3.2 Character Data


Turning ON automatic tuning is shown as an example.


- ①  The decimal point on the 4th digit blinks when the ◀ key is pressed or the dial is turned for 1 click, indicating that change is enabled. Blinks
- ②  Desired data (character) is selected by turning the dial. Blinks
- ③  The data (character) is registered by pressing the ENT key. Blinking of the decimal point stops.

[Reference] When - - - - is displayed

If - - - - is displayed when the ◀ key or dial is operated to enable change, it means that the item cannot be set. - - - - display disappears in approximately 2 seconds and returns to the original display.

5.4 System Setup

The basic functions of this controller are as shown in the following table at factory setting. To use with settings other than that of factory setting, press the  key for about 6 seconds to display the Setup screen and then change on the specified displays. To change multiple items, change in the order of the table below:

No.	Item	Screen position	Factory setting
1	Input type  Input list (page 17)	SU1	K1
2	Use of square root (for mV, V, mA input)	SU1	Not used
3	Scaling	SU1	-200 to 1370°C
4	Output type (not required for dual output specification)	SU2	mA
5	Control mode	SU2	PID
6	Control reverse/direct action	SU2	Reverse action

[Caution]

To change multiple items, be sure to follow the order of the No. The changed data may be returned to the original factory setting if they are not changed in order.

Ex.) If input type is changed after changing the control mode, the control mode returns to the factory setting at changing the input type. In such cases, check the data and change again if the data is factory setting.

[Caution] Data initialization by change in basic functions



Please note that change in 1 to 6 of the above table initializes other items (returning to the factory setting). Changed item and the items initialized by it are shown as follows:

Changed item	Initialized item
1: Input type	All data except SU6 on Setup screen
2: Use of square root	All data on Operation screen, all data on Parameter screen except PA2 and PA12, sensor correction, scaling, PV error upper and lower limit
3: Scaling (when input is TC or RTD)	SP, SP No., bias, emergency SP, and PA1 on Parameter screen, and sensor correction
3: Scaling (when input is mV, V, mA)	SP, SP No., bias, emergency SP, up/down rate, all data in CONT group on Operation screen (except control RUN/STOP), all data on Parameter screen except PA2 and PA12, sensor correction, PV error upper and lower limit
4: Output type 5: Control mode 6: Reverse/direct action	All data in CONT group on Operation screen (except control RUN/STOP), all data in PA3 to 11 and PA13 on Parameter screen, PID mode, SP No./PID No. selection, preset output, use of present output, gapped control, profiling control

Input list

Input	Code	Input range	Input	Code	Input range
TC (thermocouple) input			DC voltage, DC current input		
B	b	0 to 1820°C	mV	10	-10.0 to 10.0mV
R	r	0 to 1760°C	mV	20	0.0 to 20.0mV
R	r	0 to 1200°C	mV	50	0.0 to 50.0mV
S	s	0 to 1760°C	V	1-5	1.0 to 5.0V
K	k	-200 to 1370°C	V	0-5	0.0 to 5.0V
K	k	0.0 to 600.0°C	V	0-10	0.0 to 10.0V
K	k	-199.9 to 300.0°C	mA	AA	4.0 to 20.0mA
E	e	-199.9 to 700.0°C	RTD (resistance temperature detector) input		
J	j	-199.9 to 900.0°C	Pt	Pt0	-199.9 to 850.0°C
J	j	-199.9 to 400.0°C	100	Pt1	-199.9 to 300.0°C
T	t	-199.9 to 400.0°C		Pt2	-150.0 to 150.0°C
WRe5-			JPt	JPt0	-199.9 to 650.0°C
26	c	0 to 2320°C	100	JPt1	-199.9 to 300.0°C
N	n	0 to 1300°C		JPt2	-150.0 to 150.0°C
PR40-20	p	0 to 1880°C			
PL II	pl	0 to 1390°C			
U	u	-199.9 to 400.0°C			
L	l	-199.9 to 900.0°C			
Au-Fe	AUFE	0.0 to 300.0K			

5.5 All Reset

All Reset is the operation to return to the factory setting all parameters except for basic settings. To perform All Reset, press the  and  key simultaneously for more than 3 seconds.

[Caution] Data initialization by All Reset

All Reset maintains the following items and initializes all other items.

Group	Maintained item
SU1	Input type, reference junction compensation, use of square root, input cutoff level (when square root is used), scaling
SU2	Output type (at multi-output), control mode, control reverse/direct action, cycle time, output hysteresis width
SU3	DO function selection
SU4	DI function selection, SP No./PID No. selection
SU6	Communication address, Transmission speed, communication type

5.6 Setting Items of Each Function

This section describes the setting items and the order of setting for each of the major functions.

5.6.1 Set the Controlled SP Each Time

Order	Item	Screen/group	Factory setting
①	Set the normal SP.	SP	0
②	Set the normal PID and MR (Manual Reset: at PD control). It can be calculated automatically by automatic tuning or Self tuning (only for PID control).	Cont on Operation screen	P: 2.0% I: 3.00 min. D: 0.00 min. MR: 50%

[Caution] Normal SP and Normal PID


They are used as the SP and PID when multi-SP is disabled. Normal SP is set on normal display in AUTO. If multi-SP is enabled, 8 kinds of multi-SP and multi-PIDs that form couples with each multi-SP can be used beside this normal SP.

5.6.2 Switching SP registered beforehand

Order	Item	Screen/group	Factory setting
①	Set the use of multi-SP to "Used".	ASP on Operation screen	Not used
②	Set the multi-SP.	SP	0
③	Set the multi-PID and MR (for PD control). It can be calculated automatically by automatic tuning or Self tuning (for PID control only).	Manual setting: PA3 to PA10 (corresponds to from PID1 to 8) or Cont on Operation screen (only PID and MR in execution)	P: 2.0% I: 3.00 min. D: 0.00 min. MR: 50%
④	Set the up/down rate. *1	ASP on Operation screen	OFF(0)
⑤	Switch the multi-SP. *1		SP0 (normal SP)

*1 : Action for ④、⑤ → Section 8.3.2 (page 40)

5.6.3 Use of Alarms

Order	Item	Screen/ group	Factory setting
①	Alarm function is determined.	SU3	DO1: Deviation high alarm DO2: Deviation low alarm DO3: Deviation absolute value alarm DO4: Fail (it is not an alarm.)
②	Set the alarm value.	PA1	DO1: + scaling width Scaling width DO2: - scaling width  Lowest DO3: + scaling width column DO4: None
③	Set the use of pause alarm, hysteresis width and ON delay time.		Pause alarm is not used, hysteresis width = 0, ON delay time = 0


[Caution]

- Set the functions and the alarm values of ALM (alarm) 1 to 4 at DO1 to DO4 in SU3, PA1.
- When the number of contact output points are two (standard), contacts DO3 and DO4 are not output. However, the functions are available and similar setup to DO1 and 2 is possible. The condition can be checked by alarm/event display lamp.

[Caution] Initialization by changing alarm functions

When alarm function is changed, the alarm value, use of pause alarm, hysteresis width and ON delays time for the changed DO No. are initialized.

[Reference] Alarm type and functions

The types and functions of alarm equipped in this instrument are as follows. Furthermore, the alarm occurrence conditions in the table below are those for no pause alarm and 0 hysteresis width and 0 ON delay time (pause alarm, hysteresis width, ON delay time  Section 9.1):

Type	Function (alarm occurrence condition)
Deviation high alarm	When “deviation (PV – SP) > alarm setting value”
Deviation low alarm	When “deviation (PV – SP) < alarm setting value”
Deviation absolute value alarm	When “deviation (PV – SP) > alarm setting value”
PV high alarm	When “PV > alarm setting value”
PV low alarm	When “PV < alarm setting value”
SP high alarm	When “SP > alarm setting value”
SP low alarm	When “SP < alarm setting value”


[Reference] What is scaling width?

It indicates “scaling upper limit – scaling lower limit.”


5.6.4 Gapped Control (Nonlinear Control)

Order	Item	Screen/ group	Factory setting
①	Switch the gapped control setting to "Enabled".	SU2	Disabled
②	Set the gap width and gap gain.	PA13	Gap gain = 0.01, gap width = 0

5.6.5 Remote SP

Order	Item	Screen/ group	Factory setting
①	Set the remote SP range and use of emergency SP of isolated remote SP, or local address of expansion interface.	Isolated remote SP: SU7	1 to 5V input, No emergency SP
		Expansion I/F: SU10	Local address = 0
②	If the isolated remote SP of built-in option and expansion interface of expansion option are both equipped, whether select the use of remote SP of expansion I/F.	SU10	Expansion I/F remote SP not used (isolated remote SP used)
③	Select the PID mode (normal PID/programmed PID). *2	SU2	Normal PID
④	Select the SP No./PID No. selection (SP No. switching/PID No. switching). *2	SU5	SP No. switching
⑤	Switch the SP remote/local switching to SP remote. *2	 on Operation screen	SP local

*2: Relationship between setting and action for ③, ④, and ⑤


 Section 8.6 (page 43)

5.6.6 Profiling Control

This is the operation when it is used as master controller on profiling control. In case of using as a slave controller, set the items shown in "Section 5.6.5 Remote SP."

Order	Item	Screen/ group	Factory setting
①	Switch the profiling control to "Enabled".	SU2	Disabled
②	Select the transmission method to slave controller. In case of using AO, set AO range and output source. In case of using expansion I/F, set local address, master, output source and slave addresses. It is not required when transmitting by current from control output terminal.	AO: SU8	4 to 20mA, PV output
		Expansion I/F: SU10	Local address= 0, slave

For setting details of AO, isolated remote SP

 AO, Isolated Remote SP Instruction Manual WXPEC5500R03E

For setting details of expansion interface

 Expansion Interface, Servo Drive Instruction Manual WXPEC5500R04E

5.7 Key Lock

The key lock is the function to prevent setting by mistake. Set the key lock type in SU5 on Setup screen, and “Lock”/“Unlock” is specified in **KEY** on Operation screen. The key lock type and key lock subjects are shown as follows. Furthermore, the key lock type is set to **OFF** at the factory setting:

Key lock type	Subject
OFF	Key lock does not function.
ALL	Key lock type setting, key lock/unlock switching, AUTO/MAN switching and output setting for MAN are possible even under key lock. All other functions are subject for key lock.
MAN SP	Key lock type setting, key lock/unlock switching, AUTO/MAN switching, output setting for MAN, normal SP setting, multi-SP setting and multi-SP No. switching are possible even under key lock. All other functions are subject for key lock.
SU	Those setting on Setup screen except for key lock type settings are subjected. All other settings are possible even under key lock.



[Caution]

It becomes automatically “Lock” if the key or dial is not operated for more than 1 minute even when it is switched to “Unlock” on Operation screen when the key lock type is set to other than **OFF**.

Chapter 6 Operation Guidance


This chapter shows the transition chart of the display and the key operation.

[Reference] How to look at guidance

→ :  key movement → :  key movement



Bold frame: Displayed for factory setting



Broken line frame: Displayed for optional equipment

Italic: Cannot be set.

* mark: There are conditions for display.


[Caution] Normal display and SP display

Displayed information for normal display, normal SP display and multi-SP display vary as shown in the table below depending on the control status during AUTO operation. Furthermore, normal display is the 1st output display during MAN operation:

Control status	Lower display at normal display (at power startup)	Normal SP display	Multi-SP display
Normal SP control	Normal SP	Blank on SP No. display	Multi-SP No. display blinks (however, it is not displayed for factory setting since "multi-SP is disabled.")
Ramping control	Normal SP	Ramping SP is displayed and the decimal point for SP No. display blinks.	Decimal point on SP No. display blinks.
Multi-SP control	Multi-SP	No display	Multi-SP No. display is lit during execution and SP No. display blinks in other case.

At factory

6.1 Operation Screen



*1: n is SP No. and is displayed by the **ENT** key in order of No.1, 2...8.

*2: Displayed when the isolated remote SP or expansion I/F is used.

*3: Displayed only when the range of isolated remote SP is 1 to 5V and emergency SP is enabled.

*4: Displayed when key lock type is not **OFF**.

*5: To display the output value, press the **MAN** key. It moves to this display at each display. For single output, it is switched as SP display→ output display→ SP display every time the **MAN** key is pressed. For dual output, it is switched as SP display→ 1st output display→ 2nd output display→ SP display in a similar fashion. The **MAN** key is also used for AUTO/MAN switching.

SP/output display switching Section 8.2.1

AUTO/MAN switching Section 8.2.2

*6: n indicates the heater No. that is set up with heater address among No.1 to 3. (Displayed with the **ENT** key in order of No.1, 2 and 3: No.1 heater current→ No.1 heater resistance→ No.2 heater current→ ...)


*7: Displayed only when alarm hold is enabled and the heater monitoring unit is connected.

*8: Displayed when 1st output is PID or PD.

*9: Displayed when 1st output is PID control.

*10: Displayed when 1st output is PD control.

*11: Displayed when 2nd output is PID or PD control.



*12: Displayed when 2nd output is PID control

*13: Displayed when 2nd output is PD control

*14: n indicates SP No.

*15: Setting not allowed for group **FUNC**.


*16: Displayed only when multi-SP is used.


*17: Displayed only for dual output.

[Reference] Settings and functions

For setting details and functions, refer to Chapter 7 (Details/setting range) and Chapters 8 and 9 (Functions).

6.2 Parameter Screen





[Reference] Settings and functions

For setting details and functions, refer to Chapter 7 (Details/setting range) and Chapters 8 and 9 (Functions).

*4: n indicates the heater No. from No.1 to 3 at which the heater address is set up (displayed with the **ENT** key in order of No.1, 2, and 3: No.1 heater resistance high alarm value→ No.1 heater resistance high-high alarm value → ...→ use of No.1 heater pause alarm→ No.2 heater resistance high alarm value→ No.2 heater resistance high-high alarm value→ ...→ use of No.2 heater pause alarm→ No.3 heater resistance high alarm value→ No.3 heater resistance high-high alarm value→ ...→ use of No.3 heater pause alarm).

*5: Displayed when 1st output is PID or PD control.

*6: Displayed when 1st output is PID control.

*7: Displayed when 1st output is PD control.

*8: Display PID No.1 to 8 as **PA 3** to **PA 10**.

Multi-Pn, In, Dn, MR, (n = 1 to 8) indicate PID and manual reset corresponding to multi-SP No.n (n = 1 to 8).

*9: Displayed only when 2nd output is PID or PD control.

*10: Displayed only when gapped control is enabled.

SU 1

SENS

rAng

Input type

SCLH

Scaling H

SCLL

Scaling L

dP

Decimal point

*4

SEnC

Sensor correction

*5

rJC

Reference junction compensation

*1

Sqr

Use of Square root

*2

CoFF

Input cutoff level

*3

PLAG

First-order lag

SU 2

Cont

ALt

Multi-output

*7

Cont

Control mode

r.d

Control direct/reverse action

*7

GAP

Gapped control

*8

on. CY

Cycle time

*9

SU 3

do

DO function selection

SU 4

d.

DI function selection

dSEL

SP No./PID No. selection

*14

on. HY

Output hysteresis

*10

PrSo

Preset value

*11

PrS

Use of Preset

*11

PID mode

*12

Prof


Profiling control

*13

*1: Displayed only when the input type is TC.

*2: Displayed only when the input type is mV (other than -10.0 to 10.0mV), V, mA

*3: Displayed only when square



*4: Displayed only when the input type is mV, V, mA.

*5: Displayed only when the input type is TC or RTD.

*6: Displayed only when first-order lag is 0.

*7: Displayed only when there is no 2nd output.

*8: Displayed only when 1st output is PID control.

*9: n is output No. and display the cycle time of 1st output when it's not ON-OFF control and has SSR drive or relay output. Display the cycle time of 2nd output when it's not ON-OFF control and has SSR drive or relay output.

*10: n is output No. and display the output hysteresis width of 1st output when it's ON-OFF control. Display the output hysteresis width of 2nd output when it's ON-OFF control.

*11: Displayed only when 1st output or 2nd output is not ON-OFF control.

*12: Displayed only when 1st output is not ON-OFF control and there is isolated remote SP or expansion I/F.

*13: Displayed only when 1st output is not ON-OFF control.

*14: Displayed only when there is isolated remote SP or expansion I/F.


*15: Displayed only when there is isolated remote SP.


*16: Displayed only when there is isolated remote SP and isolated remote SP range is 1 to 5V.

*17: Displayed only when there is AO.

[Reference] Settings and functions

For setting details and functions, refer to Chapter 7 (Details/setting range) and Chapters 8 and 9 (Functions). Furthermore, refer to AO, Isolated Remote SP Instruction Manual "WXPEC5500R03E" for **SU 7** and **SU 8**.





[Caution]

Pass number is the item for factory adjustment. Do not operate it.

[Reference] Settings and functions

For setting details and functions, refer to Chapter 7 (Details/setting range) and Chapters 8 and 9 (Functions). Furthermore, refer to Expansion Interface, Servo Drive Output Instruction Manual “WSPEC5500R04E” for **SU 9**, **SU 10** and **SU 11**.

*24: Displayed only when local address is not 0.

*25: Displayed only for heater Nos. when heater address is not 0.

*24,*25: n is heater No. and the No. from No.1 to 3 at which heater address is set up is displayed (Display in order of No.1, 2 and 3 with **ENT** key: No.1 heater address→ No.1 heater high alarm function selection→ …→ No.1 current scale→ No.2 heater address→ No.2 heater high alarm function selection→ …→ No.2 current scale→ No.3 heater address→ No.3 heater high alarm function selection→ …→ No.3 current scale).

Chapter 7 List of Items

7.1 Operation Screen

Item	Upper display () indicates SP No.	Description/setting range		Factory setting
Normal SP	PV	Scaling range		0
Multi-SP	PV(n)	Scaling range n: Multi-SP No. (n=1 to 8)		0
Bias	(b)	±20% of scaling width		0
Emergency SP	(E)	Scaling range		0
1st output	PV(1)	Output lower limit to output upper limit		0
2nd output	PV(2)	2nd output lower limit to 2nd output upper limit		0
Heater current	n. HEt (A)	Heater current value	n: Heater No. (n=1 to 3) display only	
Heater resistance	n. HEt (r)	Heater resistance value		
Alarm hold	HEAt (H)	HdoF: No hold, HoLd: Holding, ArSe: Hold cancelled		HdoF
Key lock	KEY	UnLC: Key unlock LoC: Key lock		UnLC
Tuning	Cont (t)	ntUn: Normal Aton or iAt: Automatic tuning Ston: Self tuning 2At: 2nd output automatic tuning		ntUn
Execution P	Cont (P)	Execution 1st output proportional band 0.1 to 999.9%		2.0
Execution I	Cont (i)	Execution 1st output integration time 0.01 to 99.99 min.		3.00
Execution D	Cont (d)	Execution 1st output derivative time 0.00 to 20.00 min.		0.00
Execution MR	Cont (r̄)	Execution 1st output manual reset 0 to 100%		50
2nd output P	Cont (P.)	2nd output proportional band 0.1 to 999.9%		2.0
2nd output I	Cont (i.)	2nd output integration time 0.01 to 99.99 min.		3.00
2nd output D	Cont (d.)	2nd output derivative time 0.00 to 20.00 min.		0.00
2nd output MR	Cont (r̄.)	2nd output manual reset 0 to 100%		50
Dead band coefficient	Cont (b)	-0.500 to +0.500 Dead band (%) = dead band coefficient x 100		0.000

Item	Upper display () indicates SP No.	Description/setting range	Factory setting
Anti-overshoot	Cont (A)	Use of anti-overshoot nAoS : Not used, AoS : Used	nAoS
Control R/S	Cont (r)	rUn : Control RUN StoP : Control STOP	rUn
SP R/L	rEā(S)	LCL : SP local, rEā : SP remote	LCL
Communication R/L	rEā(C)	LCL : Communication local, rEā : Communication remote	LCL
Use of Multi-SP	āSP	Use of Multi-SP oFF : Not used, on : Used	oFF
Execution SP No.	āSP(n)	0 to 8 n: Multi-SP No. (n= 0 to 8, 0 is normal SP)	0
Up rate	āSP(u)	oFF (0.00) to 650.00 unit/min.	oFF
Down rate	āSP(d)	oFF (0.00) to 650.00 unit/min.	oFF

7.2 Parameter Screen

Item	Upper display	Description/setting range	Factory setting
PA1 alarms n: Alarm No. (n = 1 to 4)			
Alarm value setting	n. ooo	PV alarm: scaling range SP alarm: scaling range Deviation high alarm: 0 to + scaling width Deviation low alarm: - scaling range to 0 Deviation absolute value alarm: 0 to + scaling width ooo: DO function selection data	1: 1570 2: -1570 3: 1570 4: None
Use of pause alarm	An. PS	Use of pause alarm function oFF : Not used, on : Used	oFF
Alarm hysteresis width	An. HY	Alarm hysteresis width 0 to scaling width	0
Alarm delay time	An. dL	Alarm ON delay time 0 to 600 sec.	0
Alarm hold	An. Hd	Use of alarm hold oFF : Not used, on : Used	oFF
PA2 heater alarms n: Heater No. (n = 1 to 3)			
Heater resistance high alarm value	n. HAL	Heater resistance high alarm value 0.01 to 99.99Ω	99.99
Heater resistance high-high alarm Value	n. HHA	Heater resistance high-high alarm value 0.01 to 99.99Ω	99.99
Heater resistance change rate alarm value	n. Cr.H	Heater resistance change rate alarm value 0.01 to 99.99Ω	99.99
Specified heater high alarm value	n. EP.r	Specified heater high alarm value (display only)	

Item	Upper display	Description/setting range	Factory setting
Heater high alarm specified temperature	n. EP.H	Heater high alarm specified temperature Scaling range	100
Heater alarm judgment lower temperature	n. EP.L	Heater alarm judgment lower temperature Scaling range	100
Heater alarm judgment upper temperature	n. EP.H	Heater alarm judgment upper temperature Scaling range	1500
Use of heater pause alarm	n. HPS	Use of heater pause alarm OFF : Not used, ON : Used	OFF
PA3 to PA10 Multi-PID n: PID No. (n = 1 to 8)			
Multi-P	n. P	Multi-proportional band 0.1 to 999.9 %	2.0
Multi-I	n. I	Multi-integration time 0.01 to 99.99 min.	3.00
Multi-D	n. d	Multi-derivative time 0.00 to 20.00 min.	0.00
Multi-MR	n. MR	Multi-manual reset 0 to 100%	50
PA11 Output limit			
Output upper limit	OL.H	1st output upper limit Lower limit to 100	100
Output lower limit	OL.L	1st output lower limit 0 to upper limit	0
2nd output upper limit	OL.H2	2nd output upper limit 2nd output lower limit to 100	100
2nd output lower limit	OL.L2	2nd output lower limit 0 to 2nd output upper limit	0
PA12 PV start			
PV start	PVS	OFF : Disabled, ON : Enabled	OFF
PA13 Gapped control			
Gap gain	GAP.G	0.01 to 0.50	0.01
Gap width	GAP.W	0 to 50%	0

7.3 Setup Screen

Item	Upper display	Description/setting range	Factory setting
SU1 Sensor			
Input type	RAI	Refer to Input list (page 17)	RI
Scaling H	SCL.H	Scaling upper limit value TC or RTD input: Range DC input: -1999 to +9999 (decimal point position follows the setting.)	1370
Scaling L	SCL.L	Scaling lower limit value TC or RTD input: Range DC input: -1999 to +9999 (decimal point position follows the setting.)	-200
Decimal point	DP	Scaling value below decimal point 0 to 3	0

Item	Upper display	Description/setting range	Factory setting
Sensor correction	SEn.C	-100.0°C to 100.0°C	0
Reference junction compensation	r.JC	Reference junction compensation oFF: Disabled, on: Enabled	on
Use of square root	Sqr	oFF: Not used, on: Used	oFF
Input cutoff level	C.oFF	Input cutoff level at square root 0.0 to 25.0%	10.0
First-order lag	P.LAG	0 to 20 sec.	0
Moving average	Aur.G	Moving average times 1 to 8	8
PV error upper limit	Pu.H	-1999 to +9999 (decimal point position follows the setting.)	1402
PV error lower limit	Pu.L		-231
SU2 Control/output n: Output No. (n=1,2)			
Multi-output	ALt.	AA: Current, Ssr: SSR drive, rLy: Relay	AA
Control mode	Cont	P id: PID control (both outputs for dual output) Pd: PD control (both outputs for dual output) onof: ON-OFF (both outputs for dual output) P-on: PID for 1st output + ON-OFF control for 2nd output on-P: ON-OFF for 1st output + PID control for 2nd output	P id
Control direct/reverse action	r.d	Control action rEu: Reverse action, dir: Direct action	rEu
Gapped control	GAP	oFF: Disabled, on: Enabled	oFF
Cycle time	on.CY	Output cycle time 1 to 120 sec. Cycle type = Output ON time + output OFF time	60
Output hysteresis width	on.HY	0.00 to 20.00%	0.10
Preset value	PrSo	Preset output value Output lower limit to output upper limit	0
Use of preset	PrS	Use of preset output oFF: Not used, on: Used	oFF
PID mode	P id.n	Selection of PID to be used during remote SP execution nor: Normal PID, P.P id: Programmed PID	nor
Profiling control	ProF	Profiling control as master controller oFF: Disabled, on: Enabled	SLu

Item	Upper display	Description/setting range	Factory setting
SU3 DO functions n: DO No. (n = 1 to 4)			
DO function selection	do	Alarm: n. duH : Deviation high alarm, n. duL : Deviation low alarm, n. Ad I : Deviation absolute value alarm, n. PuH : PV high alarm, n. PuL : PV low alarm, n. SPH : SP high alarm, n. SPL : SP low alarm, n. HEA : Heater monitoring alarm Status output: n. FAL : Failure output (contact ON at CPU error and error in self diagnostics) n. KEP : Keep arrival output (contact ON from ramping completion to SP change or start of next ramping) n. MAN : MAN output (contact ON at MAN) n. SEP : STOP (contact ON at control STOP)	1duH 2duL 3Ad I 4FAL
SU4 DI functions n: DI No. (n = 1 to 4)			
DI function selection	d	n. SPn : SP No. switching or PID No. switching (follows the setting for SP No./PID No. selection.) n. MAN : AUTO/MAN switching (MAN with contact ON) n. REn : SP remote/local switching (SP remote with contact ON) n. SEP : STOP (control STOP with contact ON)	All 4 points SPn
SP No./PID No. selection	dSEL	DI functions while remote SP is in execution SPno : SP No., P idn : PID No.	SPno
SU5 Key lock			
Key lock type	ELoC	oFF : None (no key lock function) ALL : All data subjected nSP : All data except SP subjected SU : The data on Setup screen subjected	oFF
SU6 Communication			
Transmission speed	bPS	300 :300bps, 600 :600bps, 1200 :1200bps, 2400 :2400bps, 4800 :4800bps, 9600 :9600bps,	9600
Communication address	AdrS	0 to 31	0
Communication type	CSEL	orG : Original protocol, ModA : Modbus protocol (ASCII mode), Modr : Modbus protocol (RTU mode)	orG

Item	Upper display	Description/setting range	Factory setting
SU7 Isolated remote SP Function details, AO, Isolated Remote SP Instruction Manual WXPEC5500R03E			
R-SP range	R-SP	Remote SP range 1-5 : 1 to 5V, 0-5 : 0 to 5V	1-5
Use of emergency SP	E.SP	OFF : Not used, ON : Used	OFF
SU8 AO Function details, AO, Isolated Remote SP Instruction Manual WXPEC5500R03E			
AO range	A-SP	0-20 : 0 to 20mA, 4-20 : 4 to 20mA	4-20
AO source	A.S-C	Pu : Process variable, SP : Setpoint, OUT : Output value	Pu
SU9 Servo drive Function details, Expansion Interface, Servo Drive Output Instruction Manual WXPEC5500R04E			
Dead band	dEdb	Servo dead band 0.5 to 10.0%	1.0
Servo status	S.OP	S-Run : during operation, S.Adj : Automatic calibration start	S-Run
Closed calibration	CLOS	A/D count value at automatic calibration Close (zero)	
Open calibration	OPEN	A/D count value for automatic calibration Open (span)	
Calibration completion	S.OP	S.End : Automatic calibration normal completion, Err : Error occurrence, S-Run : Operation start	
SU10 Expansion I/F n: Slave No. (n = 1 to 3) Function details, Expansion Interface, Servo Drive Output Instruction Manual WXPEC5500R04E			
Local address	LCAd	Expansion I/F local address 0 to 255	0
Master/slave	A-S	SLu : Slave, MASt : Master	SLu
Expansion remote SP	-EA	Remote SP by expansion I/F enabled/disabled OFF : Disabled (isolated remote SP enabled), ON : Enabled	OFF
Output source	S-C	Pu : Process variable, SP : Setpoint, OUT : Output value	SP
Slave address	Sn. Ad	Expansion I/F EC address 0 to 255.	0

Item	Upper display	Description/setting range	Factory setting
SU11 Heater monitoring n: Heater No. (n = 1 to 3) Function details, Expansion Interface, Servo Drive Output Instruction Manual WXPEC5500R04E			
Local address	LCAd	Expansion I/F local address 0 to 255	0
Heater address	Hn. Ad	Expansion I/F heater address 0 to 63	0
Heater high alarm function selection	n. HAL	Heater resistance high alarm function selection 0 to 4 (= 0: None, = 1 to 4 correspond to DO numbers.)	0
Heater high-high alarm function selection	n. HHA	Heater resistance high-high alarm function selection 0 to 4 (= 0: None, = 1 to 4 correspond to DO numbers.)	0
Heater change rate alarm function selection	n. CRH	Heater resistance change rate alarm function selection 0 to 4 (= 0: None, = 1 to 4 correspond to DO numbers.)	0
Heater temperature high alarm function selection	n. TEP	Heater temperature high alarm function selection 0 to 4 (= 0: None, = 1 to 4 correspond to DO numbers.)	0
Heater break alarm function selection	n. brt	Heater break alarm function selection 0 to 4 (= 0: None, = 1 to 4 correspond to DO numbers.)	0
Voltage scale	n. SCv	Heater voltage scaling 1.0 to 999.9V	According to setting in ZE7201
Current scale	n. SCA	Heater current scaling 1.0 to 999.9A	5.0
SU12 (Not used)			
SU13 For factory adjustment			
Pass number	nUAb	Secret number	0

Chapter 8 Operation

8.1 Control Method

Control methods are classified into automatic operation (AUTO) and manual operation (MAN).

Control method	Output	MAN lamp
AUTO	Output is calculated by controlled computing of PID, etc. Output cannot be set manually.	OFF
MAN	Operation is executed with the set output.	ON

8.2 Automatic Control (AUTO) and Manual Control (MAN)

8.2.1 SP/Output Display Switching

The **(MAN)** key is used for switching of display between SP and output. Display of SP and output is switched every time the **(MAN)** key is pressed. Operation and displayed data for single output type and dual output type are shown as follows:

Furthermore, PV is always displayed on the upper display.

(1) Single output type

Every time the **(MAN)** key is pressed, display of ① and ② alternate with each other.

	At AUTO			At Man		
	Lower display	SP No. display	MAN lamp	Lower display	SP No. display	MAN lamp
①	Output value	1	Blinks	Output value	1	ON
②	SP	Blank or multi-SP No. *1	OFF	SP	Blank or multi-SP No. *1	Blinks

(2) Dual output type

Every time the **(MAN)** key is pressed, display is switched in order of ①→②→③→④→...


	At AUTO			At MAN		
	Lower display	SP No. display	MAN lamp	Lower display	SP No. display	MAN lamp
①	1st output value	1	Blinks	1st output value	1	ON
②	2nd output value	2	Blinks	2nd output value	2	ON
③	SP	Blank or multi-SP No. *1	OFF	SP	Blank or multi-SP No. *1	Blinks

*1: Blank at normal SP execution, multi-SP No. at multi-SP execution.


8.2.2 AUTO/MAN Switching

When the **ENT** key is pressed during MAN lamp blinking (refer to Sec. 8.2.1 on previous page), the control switches to MAN if the current control is AUTO and to AUTO if the current control is MAN.

AUTO→MAN switching



MAN→AUTO switching



- When AUTO→MAN: Switch to MAN while maintaining the output value immediately before switching.
- When MAN→AUTO: Switch to bump-less from the output value immediately before switching and control is started from this value.

[Caution]

For dual output, it is only 1st output that switches to bump-less at MAN to AUTO switching. 2nd output is not changed to bump-less. However, 2nd output switches to bump-less if 1st output is ON-OFF control and 2nd output is not ON-OFF control.

[Caution]

When AUTO/MAN switching is set up by DI function selection, AUTO/MAN switching with surface key or communication is disabled.

8.2.3 Setting Output Value at MAN


Output value can be changed directly by dial during MAN operation. The value is immediately reflected on the output when the dial is turned. There is no need to press the **ENT** key for registering the value. When ON-OFF control is used, it changes to 100 when the dial is turned to clockwise and to 0 when it is turned to anti-clockwise.

[Caution] Caution during MAN operation


Please note that the value is immediately outputted when the dial is turned while the output value is displayed.

8.3 SP

8.3.1 Normal SP and Multi-SP

In this instrument, the values can be registered in normal SP and 8 kinds of SPs (multi-SP) assigned to No.1 to 8 and used. There is a couple PID for each SP No. and it automatically switches the PID value to be used in interlock with the execution SP No. (except when remote SP is executed.  Section 8.6 of this chapter).

8.3.2 Multi-SP Setting, Switching and Ramping

When “use of multi-SP” is set to “Used,” setting of multi-SP, up/down rate values and switching of multi-SP are enabled. “Use of multi-SP” is set to “Not used” at factory setting. Setting and switching with surface keys are executed on Operation screen. Switching of multi- SP can be executed from surface key, external communication or DI contact. Multi-SP is switched using a surface key by changing the SP No. displayed on SP No. display in **SP** on Operation screen with the dial. Every time the dial is turned, the SP that corresponds to the SP No. is displayed on lower display (conditions for multi-SP switching  Section 8.6 of this chapter).

The action when multi-SP is switched varies as shown in the table below by the setting of up/down rate. During SP ramping, the decimal point on SP No. display blinks for each display of normal SP, multi-SP, bias, emergency SP, multi-SP switching, up/down rate and output.

Multi-SP switching	Rate setting	Action
Switching to multi-SP larger than current SP	Up rate is not OFF	SP ramping is executed to the new multi-SP according to up rate value.
	Up rate is OFF	SP immediately shifts to new multi-SP.
Switching to multi-SP smaller than current SP	Down rate is not OFF	SP ramping is executed to the new multi-SP according to Down rate value.
	Down rate is OFF	SP immediately shifts to new multi-SP.
Switching from multi-SP to normal SP		Current SP is maintained regardless of rate setting (current SP is moved to normal SP without change). However, it immediately shifts to remote SP when the optional remote SP is enabled.

[Caution]

The maximum value for ramping time is approx. 1165 hours (approx. 69905 min.). If ramping time exceeds this, display **Err2** for about 2 seconds at the start of ramping and execute ramping at the maximum ramping time.

8.3.3 PV Start

PV start functions at multi-SP switching or at turning on the power during ramping or multi-SP execution. However, it is limited to cases in which the down rate setting is not 0 (OFF) if PV > target SP and the up rate setting is not 0 (OFF) if PV < target SP at beginning of PV start. At beginning of PV start, SP becomes equal to PV and then ramping is executed for the target multi-SP with the setting up/down rate. If PV display is H or L (outside the range of PV error upper and lower limit values), ramping is executed from SP = 0.

8.3.4 Anti-Overshoot

It functions when SP is changed in steps or ramped, and suppresses overshoot near the target SP. It functions only when the control mode is single output type and PID control.

8.4 Automatic Tuning

Output is changed as 0 ↔ 100% (lower output limit ↔ upper output limit for current output) to measure the process property from the change in process variable.

Tuning is started by selecting **AtOn**, **1At** (subjecting 1st output in dual output) or **2At** (subjecting 2nd output in dual output) is selected in **Cont** on Operation screen, and TUNE lamp blinks. Tuning is stopped when **AtUn** is selected during automatic tuning, and PID does not change. It changes automatically to **AtUn** when tuning is completed, and TUNE lamp goes OFF.

[Caution] Precautions in automatic tuning

The process value (i.e.: furnace temperature) increases/decreases when tuning is executed. Be sure to check that there is no hitch for the system or product before executing.

8.5 Self Tuning

Unlike automatic tuning which is executed only when the operator intends it, Self tuning is the function to execute tuning automatically when the stability of control exceeds the limit or setting changes in steps, etc. by monitoring the existence of hunting, deviation, etc. continuously by the controller. Since the output is not changed in steps as in automatic tuning, there is no disturbance by tuning.

The conditions to update the PID to optimal value during Self tuning (when display is **StOn** and TUNE lamp is ON) are as next page:

- a: When SP is changed by 0.5% FS (full scale) or larger in steps with stable PV,
- b: When PV or output fluctuation is detected for 3 cycles for more (it may take more time depending on the furnace features and the PID value at fluctuation),
- c: When PV is stable and SP is larger than PV by 2% FS or larger at turning on this instrument.

[Reference]

PV stability is judged by the following conditions:

At turning on the power: Stability within $\pm 0.08\%$ FS continues for 2 seconds or longer.

At normal control: Stability within $\pm 0.08\%$ FS continues for 1/2 of the current integration time.

[Caution] Precautions for use

Self tuning execution is maintained when turning off the power during Self tuning. An inappropriate PID may be calculated if the furnace is turned on the power after changing SP with furnace power OFF during Self tuning. Change SP with the furnace power ON. Turns off the instrument once and then turns on again if the difference between SP and PV stays large even if the specified period (it varies by the furnace characteristics) passes.

[Caution]

PID calculated by Self tuning may not give favorable control depending on the furnace features, though it is a rare case. In such cases, stop Self tuning and calculate PID by automatic tuning.

[Caution]

Though PID can be changed manually from surface key or external communication during Self tuning, the set PID may be overwritten by the tuning result depending on the control status.

[Caution]

Self tuning can be executed for single output type with PID control, reverse action, no square root and except the master controller of profiling control. In addition, TUNE lamp goes OFF during MAN and control STOP even when Self tuning is ON, and Self tuning is not operated during this period.

8.6 Selection of Operation Method

Operation method is selected by the setting on SP remote/local, SP No./PID No. selection and PID mode. The SP No. switching method and the SP and PID to be used are decided by these settings. The relationship between these settings and action is shown in the table below:

×: Setting does not affect.

Setting				Operation method/action					
SP remote/local switching on Operation screen	SP No. switching (DI function) on Setup screen	Type	PID mode (PID No. selection) on Setup screen	SP No. switching method	At normal SP execution		At multi-SP execution		
Remote switching	DI function	Remote SP *1	PID mode		SP	PID used	SP	PID used	
SP remote	SP No. switching	Yes	Normal	External DI contact	Remote SP *2	Normal PID	Multi-SP	PID corresponding to SP No.	
			Programmed			PID corresponding to SP is automatically selected from PID No. 1 to 8.			
		No	(No setting)		Normal SP	Normal PID			
	PID No. switching	Yes	×	Disabled	Remote SP *2	PID for the No. selected in DI	Multi-SP execution disabled		
		No	(No setting)		Normal SP				
SP local	×	×	×	Surface key or external communication	Normal SP	Normal PID	Multi-SP	PID corresponding to SP No.	

*1: Remote SP is set to "Yes" when either or both of built-in option, isolated remote SP or expansion option, expansion I/F are equipped, and "No" when neither is equipped.

*2: It is impossible to change normal SP with key or communication while remote SP is being executed.

[Caution]

When SP remote/local switching is set up by DI function selection, SP remote/local switching with surface key and communication is disabled.

8.7 Power Failure and Power Restoration during Operation

If power failure occurs during operation, the action at power restoration will be as follows:


Power failure period Item	Approximately 50msec or longer			Approximately 50msec or shorter
Display	Normal display will be shown.			Everything is maintained and control continues.
SP	Execution SP at power failure	SP action after power restoration		
	Normal SP	The value before the Power failure is maintained.		
	Multi-SP	Maintained if PV start is not enabled. Ramping is started again from the PV at power restoration when PV start is enabled.		
	During ramping	Ramping is started again from the start SP when PV start is not enabled and from the PV at power restoration when PV start is enabled.		
Output	Control method at power failure	Use of preset	Output at power restoration	
	AUTO	Not used	AUTO status is maintained and output becomes the output lower limit.	
		Used	It is switched to MAN and the output becomes the preset value.	
	MAN		The value before the Power failure is maintained.	
Control	The output value when AUTO status is maintained is calculated newly with current PV and SP, and starts controlling.			
Alarm status	Alarm judgment is newly started from power restoration.			
Others	All other items are maintained.			

Chapter 9 Procedure for Major Functions

9.1 Alarms


9.1.1 Pause Alarm

This function is validated after turning on the power or after changing the setpoint (SP) or alarm value. An alarm doesn't occur even if it is in an alarm range (both or either of PV and SP at values where an alarm is occurred if usual) if it doesn't pass in a normal range (both PV and SP at values where an alarm is not occurred). The figure below shows an example of PV alarm.




9.1.2 Hysteresis Width

This is the function to continue alarm occurrence in the range of setting hysteresis width when it shifts from alarm range to normal range. It does not function for shift from normal range to alarm range.



9.1.3 ON Delay Time


This is the function to delay alarm occurrence for the setting period when it turned on the power (in alarm range) or when it shifts from normal range to alarm range.



9.2 Output Limit

Output limit operates as shown in the figure on the lower. An independent value can be set for each of 1st output and 2nd output. When output limit is changed, proportional band (P value) is compensated automatically.

$$P \text{ after compensation} = \frac{\text{New output limit width}}{\text{Old output limit width}} \times P \text{ before change}$$



9.3 Input Functions

9.3.1 Scaling

- (1) When input is TC, RTD,

The upper and lower limit values for scaling function as setting limits. For example, when scaling is executed for 0 to 1200°C with input range of -200 to 1370, setting less than 0°C or higher than 1200°C cannot be given.

- (2) When input is mV, V, mA,

PV and SP display for input can be set optionally in the range of -1999 to 9999.


9.3.2 Square Root

Enabled for mV (except 0.0 to $\pm 10.0\text{mV}$), V, mA input. The following formula is used to calculate the process variable (PV) from input:

$$PV = \sqrt{\text{input} \times 10}$$

Furthermore, $PV = 0$ is set compulsorily if input is smaller than the input cutoff level.

Ex.) PV stays 0 until 50% when input cutoff level is set to 25%.



9.3.3 Sensor Correction

Correction value up to $\pm 100.0^\circ\text{C}$ can be added uniformly to PV in all measurement range. However, it is limited to TC or RTD input. The PV to be displayed and the PV to be used in control are those that added the sensor correction value to the input signal after linearization.

9.4 Control RUN/STOP


PV display blinks and the preset value is outputted compulsorily when it is changed to Control STOP by surface key, external communication or DI contact. PV display blinking stops and control is started from the preset value when it is changed back to control RUN.

[Caution]

When control STOP is set up by DI function selection, control RUN/STOP switching with surface key or communication is disabled.


9.5 ON-OFF Control Hysteresis Width

Specifies the point for output ON/OFF. The value is set as the ratio to scale width.



9.6 Profiling Control

It is a type of cascade control in which the range of remote setting value change for the slave controller is restricted. Master controller adds the value obtained by converting -50 to +50% with 50% PID computing result as 0% into $\pm 7\%$ with the master SP converted into %, and transmits it to the slave controller. The slave controller receives “SP + output” from the master controller using isolated remote SP (analog value reception) or remote SP function of expansion I/F (digital value reception).



[Caution] Output value display for master controller

The output result on display is the control result. When profiling control is used, output value differs from the display output value and it is the value calculated by profiling computing.

For isolated remote SP,

➡ AO, Isolated Remote SP Instruction Manual WXPEC5500R03E


For expansion I/F,

➡ Expansion Interface, Servo Drive Output Instruction Manual
WXPEC5500R04E

9.7 Gapped Control (Nonlinear Control)

Nonlinear PID control is the control method in which deviation changes the proportional gain inside/outside the gap width centering on setting value (SP).

- When $|\text{Deviation}| \leq \text{gap}$, : Proportional gain \times gap gain
.....output change is small.
- When $|\text{Deviation}| > \text{gap}$, : Proportional gain $\times 1$
.....output change is large.



[Caution] P (proportional band) display

P (proportional band) display value is not changed even when proportional gain changes inside/outside gap width.


9.8 Heat/Cool Control

Heat/cool control outputs the heating output value and cooling output value calculated based on the PID computing results using either PID value for heating side (1st output) or PID value for the cooling side (2nd output). If either is ON-OFF control, PID value for the other side is always used. However, if both heating and cooling are ON-OFF control, deviation (SP - PV value) is used instead of PID computing result. The PID value to be used is selected automatically from PID computing results.

Heating PID is used when PID computing result $\geq 50\%$.


Cooling PID is used when PID computing result $< 50\%$

Dead band functions centering on 50% of PID computing result or 0% deviation (when both outputs have ON-OFF control) (Figure below). Output limit can be set independently for each of heating control and cooling control.




The action in each control mode is as follows (dead band > 0):


1) PID or PD control for both outputs




2) ON-OFF for 1st output, PID control for 2nd output



3) PID for 1st output, ON-OFF control for 2nd output



4) ON-OFF control for both outputs



[Caution]

When heating/cooling control is used, control reverse/direct action cannot be switched. Heating side is fixed to reverse action and cooling side to direct action.

Chapter 10 Troubleshooting

	Trouble	Cause	Remedy
Display/setting	Nothing is displayed.	Power supply is not input correctly.	Check the power supply voltage and power supply wiring. If power supply voltage and wiring are correct, contact our dealer where you purchased the instrument or our sales representative.
	---- is displayed and setting is not enabled when turning the dial or pressing the key to set.	Key lock is enabled.	Execute key unlock.
		Communication remote is enabled.	Switch communication remote/local to local.
	Normal SP cannot be set.	Remote SP is being executed.	Switch SP remote/local to local
		Ramping is being executed.	Set the SP No. back to 0.
		Automatic tuning is being executed.	Wait for completion of automatic tuning or stop it.
	PID cannot be set.		
	Multi-SP switching cannot be executed from the surface key.	SP remote is enabled.	Switch SP remote/local to local or switch with DI contact.
	PV displays H or L .	Input exceeds the PV error upper and lower limit value.	Check the input wiring and sensor. If wiring and sensor is correct, check the PV error upper and lower limit value settings.
	AdEr is displayed. *1	There is failure in input circuit.	If the same phenomenon is seen even when input terminal is short-circuited, contact our dealer where you purchased the instrument or our sales representative.
	EREr is displayed. *1	Atmosphere for use is outside that range of -20 to 80°C.	Check the atmosphere for use and contact our dealer where you purchased the instrument or our sales representative if it is within the range.
	FEEr is displayed. *1	There is failure in non-volatile memory.	If the same phenomenon is seen after All reset and change of input type, contact our dealer where you purchased the instrument or our sales representative.

	Trouble	Cause	Remedy
Display/setting	CLE or AL is displayed. *1	There is an error in calibration data.	Contact our dealer where you purchased the instrument or our sales representative.
	LE or AL is displayed. *1	There is an error in optional card.	Contact our dealer where you purchased the instrument or our sales representative.
	PV display is shifted.	Wrong setting of input type, sensor correction, etc.	Check the items in SU1 on the Setup screen.
		Error, misconnection, etc. at detector or compensating lead wire.	Check the detector, compensating lead wire, connection, etc.
	Abnormal value or character is displayed on PV.	There may be error in CPU.	Execute power re-startup, All reset, or change of input type. If the same phenomenon is still seen, contact our dealer where you purchased the instrument or our sales representative.
	C.P.E is displayed. *1		
Control	Output is not transmitted.	Restriction by output limit, MAN operation, automatic tuning being executed, control STOP, etc.	Remove each cause.
		Error display by self diagnostics PV has H or L display.	Remove each cause.
	PV does not match SP.	Insufficient heater POWER, restriction by output limit, inappropriate manual reset value for PD control, etc.	Remove each cause.
	Control is not favorable.	Inappropriate control parameter (PID, etc.)	Execute tuning.
Alarm	Alarm does not function.	DO function selection is wrong or is on pause.	Check the DO function selection and pause alarm.

[Caution]

*1 is nonconformity revealed by the self diagnostics function of this instrument. In such cases, the preset value (when preset output is enabled) or output lower limit value (when preset output is disabled) is output. It is also output when PV has **H** or **L** display. Furthermore, the DO contact set in **FAL** turns ON in case of nonconformity found by self diagnostics function.

For questions about this instrument, please inform us of the model number and manufacture number inscribed on the nameplate inside the instrument (or on case surface).

Ohkura 大倉電気株式会社

Ohkura Electric Co., Ltd.

Head Office / Factory Saitama, JAPAN

Sales Offices Tokyo, Osaka, Nagoya, Kyushu, Tohoku

URL <http://www.ohkura.co.jp/>

E-mail (in English) intsales@ohkura.co.jp

〈改版履歷〉 WXPEC5500R01E

本ページは社内配布用です。

版数	日付	作成	調査	承認	内 容	図変通知 No.
1	'06.02.15	関本	/	尾川		
2	'06.10.06	関本	/	熊井	0/55:第2版、9/,13/,22/,38/,45/:章名文字切れ修正、9/注記の round削除、17/k2入力レンジ誤記訂正、19/:警報機能誤記訂正、35/ 誤記訂正、55/:連絡先表記変更	220-060159