



[illegible][illegible][illegible][illegible]

- [illegible]

- | HXP <sup>RM</sup> 18mmG0002E | 頁数<br>2頁 | 業         | 版   | 年月日設計承認 | 變更事項 | II |  |  |  | IV |  |
|------------------------------|----------|-----------|-----|---------|------|----|--|--|--|----|--|
| I                            | 65.9.25  | 木口紙<br>細目 | III |         | III  |    |  |  |  | V  |  |

HXP <sub>RM</sub> 18mmG0002E	7頁	葉
版 I	年月日設計 65.9.25 未 細部	承認 細部
變更事項	II	IV
	III	V

- | HXP <sub>RM18mmG0002E</sub> | 頁数<br>7頁 | 業 | 版  | 年月日 | 設計 | 承認  | 變更事項 | II |  |  | IV |  |
|-----------------------------|----------|---|----|-----|----|-----|------|----|--|--|----|--|
| I                           | 65.9.25  | 未 | 川口 | 細田  |    | III | V    |    |  |  |    |  |

HXP <sub>RM</sub> 18mmG0002E	7頁 葉								
版	年月日設計承認	變更事項	II						
I	95.9.25	未決	III					V	

[illegible][illegible][illegible]

⚠ ; Matters to be attended to prevent an accident or a damage in handling  
of the equipment  
[Note] ; Note for a proper use  
[Reference] ; Reference for your operation

The revision of the Recorder Manual will be made without any prior notice. No part of this manual may be reproduced in any form by any means including photocopying, without permission from the publisher.

HXP <sup>4</sup> <sub>RM18mnG0002E</sub>						頁	
版	年月日	設計	承認	變更	事項	Ⅱ	Ⅲ
I	95.9.25	山口 細野					V
							IV



The following points are to be attended especially for a proper and safe use of the recorder. Be sure to read carefully.

1. Power-on:

Before turning on power to the recorder, check whether the ground is made properly.  
(For prevention of electric shock)

Before turning on power to the recorder, check whether the voltage of power meet with the specifications.

2. Ground:

In the event that the ground is not made properly, the recorder may become dangerous to handle. Make sure of proper ground, after the ground of recorder was made. Do not cut the ground wire of recorder or remove the connected wire with ground terminal.

### 3. Fuse:

Use the fuse assigned by our company (for prevention of fire). Do not make a short circuit at fuse holder. In case of replacement of fuse, you'd better to turn off power to the recorder, and turn off even a main power source.

4. Troubles of ground or fuse:

In case of troubles of ground or fuse, you have to turn off power to the recorder, and turn off even a main power source.

5. Wiring:

The wiring for input and output should be done after confirming a proper ground.

## 6. Environment:

The recorder should be installed at a safe environment. It is very dangerous to install the recorder at the place where an inflammable or explosive matter is being placed.

7. Taking out of main unit:

Before taking out of main unit from case, turn off power to the recorder.  
(For prevention of electric shock)

8. Handling of main unit:

Do not touch the switch, etc. of internal unit of recorder. Do not replace the main unit or the printed circuit board. In the event that you have done any of the above replacement, we do not guarantee the actuation of the equipment. Be sure to contact with our agent or our salesman in such case.

# CONTENTS

## CONTENTS

1. UNPACKING RECORDER	
1.1 Checking Accessories .....	1 - 1
1.2 Checking Model and Specifications .....	1 - 2
1.3 Removing Shipping Screws and Protector .....	1 - 4
1.4 Temporary Storage .....	1 - 5
1.5 Repacking Recorder .....	1 - 5
2. OVERVIEW OF RECORDER	
2.1 Overview .....	2 - 1
2.2 Features .....	2 - 1
3. NAMES OF COMPONENTS .....	3 - 1
4. INSTALLATION ON PANEL	
4.1 Notes for Installation .....	4 - 1
4.2 Outside Dimensions and Panel Cutout Dimensions .....	4 - 2
4.3 Installing Recorder on Panel .....	4 - 3
4.4 Fixing the Rear Part of Case to Panel (Earthquake-proof Specifications) (Option) .....	4 - 4
5. WIRING	
5.1 Terminal Array .....	5 - 1
5.2 Wiring of Power Supply .....	5 - 1
(1) Notes on wiring of power supply .....	5 - 1
(2) Wiring procedures .....	5 - 1
5.3 Input Wiring .....	5 - 2
(1) Notes on input wiring .....	5 - 2
(2) Wiring procedures .....	5 - 2
5.4 Wiring for Common Alarm Output and Fail Output .....	5 - 4
(1) Notes on wiring .....	5 - 4
(2) Wiring procedures .....	5 - 4
5.5 Wiring to DI/DO (Option) .....	5 - 5
(1) Notes on wiring for DI .....	5 - 5
(2) Notes on wiring for DO .....	5 - 5
(3) An example wiring for DI .....	5 - 5
(4) Wiring procedures .....	5 - 6

## CONTENTS

### 6. PREPARATION FOR OPERATION

- 6.1 Setting Chart Paper ..... 6-1
- 6.2 Setting a Ribbon Cassette ..... 6-4
- 6.3 Power-on ..... 6-5
- 6.4 Status after Initialization ..... 6-6

### 7. DISPLAY AND KEYS

- 7.1 Display ..... 7-1
- 7.2 Functions under Usual Operation (User Modes) ..... 7-2
- 7.3 Names and Functions of the Keys ..... 7-3

### 8. RECORD AND PRINTING

- 8.1 Multipoint discrimination for 30 Channels ..... 8-1
- 8.2 Printing ..... 8-1
  - (1) An example of log print (12-point recorder) ..... 8-1
  - (2) An example of list print ..... 8-2
  - (3) An example of comment print ..... 8-2
  - (4) A print example of time and date ..... 8-3
  - (5) A print example of alarm mode-On/Off (Option) ..... 8-3
  - (6) A print example of measured value of scale (Option) ..... 8-4
  - (7) A print example of change of range (Option) ..... 8-4

### 9. RECORDING AND OPERATION (USER MODE)

- 9.1 Parameters for Setting User Modes ..... 9-1
- 9.2 A Summary Chart of Recording and Operation (User Mode) ..... 9-3
- 9.3 Recording and Operation Procedures ..... 9-4
  - ① Locking and unlocking key ..... 9-4
    - (1) Locking key ..... 9-4
    - (2) Unlocking key ..... 9-4
    - (3) KEY LOCK state ..... 9-4
  - ② Indication of measured value by auto mode (Auto Mode) ..... 9-5
    - (1) Selection of auto mode ..... 9-5
  - ③ Indication of measured value by manual mode (Manual Mode) ..... 9-5
    - (1) Selection of Manual Mode ..... 9-5
    - (2) Manual Mode 1 and 2 ..... 9-6
  - ④ Setting indication of time, day, month, year (Clock Mode) ..... 9-7
    - (1) Indication of time, day, month, year ..... 9-7
    - (2) Changing of time, day, month, year ..... 9-8

# CONTENTS

⑤	Setting and indication of feeding speed of chart paper (Chart Mode) .....	9 - 9
(1)	Indication of feeding speed of chart paper .....	9 - 9
(2)	Changing of setting for feeding speed of chart paper .....	9 - 10
(3)	Changing feeding speed (1st, 2nd) .....	9 - 11
⑥	Changing recording function - RUN/STOP .....	9 - 12
⑦	Quick-feeding (FEED) of chart paper .....	9 - 12
⑧	Log print (Print Mode) .....	9 - 13
(1)	Print mode .....	9 - 13
(2)	Selection of print mode .....	9 - 13
(3)	Printing priority .....	9 - 14
(4)	Log print .....	9 - 14
⑨	List print (Print Mode) .....	9 - 15
⑩	Setting interval log print (Print Mode) .....	9 - 16
(1)	Setting interval log print .....	9 - 16
(2)	Changing interval log print function .....	9 - 17
(3)	Interval log print function and printing interval .....	9 - 18
(4)	Changing of printing interval of log print .....	9 - 20
(5)	Setting of printing with maximum, minimum, and average value (Option) .....	9 - 22
(6)	Setting of printing with integrating value (Option) .....	9 - 22
⑪	Setting comment print and its printing (Print Mode) .....	9 - 23
(1)	Comment printing .....	9 - 23
(2)	Checking comment data .....	9 - 24
(3)	A List of character codes .....	9 - 25
(4)	Changing comment data .....	9 - 26
⑫	Setting plot skip function (Print Mode) .....	9 - 27
(1)	Plot skip function .....	9 - 27
(2)	Setting plotting OFF .....	9 - 28
⑬	Setting alarm function (Alarm Mode) .....	9 - 29
(1)	Alarm function .....	9 - 29
(2)	Designation of DO number .....	9 - 30
(3)	Display screen of alarm mode .....	9 - 30
(4)	Checking alarm setting .....	9 - 32
(i)	Auto-checking of alarm setting .....	9 - 32
(5)	Changing alarm mode setting .....	9 - 33
(i)	Selection of alarm setting point for change .....	9 - 33
(ii)	Changing alarm setting point .....	9 - 34
(6)	Selection new alarm function ON/OFF (Option) .....	9 - 35

## CONTENTS

(7) Changing alarm output (D0) number setting	9-36
(i) Selection of alarm (D0) setting for change	9-36
(ii) Changing alarm output (D0) setting	9-37
⑭ Checking state of alarm-ON	9-38
(1) Indicatin of alarm	9-38
(2) Alarm output	9-38
(3) Checking of the set alarm point and alarm output	9-38
⑮ Execution of new alarm reset (Alarm Mode)	9-39
(1) Execution of new alarm reset	9-39
(2) New alarm reset function	9-39
(i) Indication	9-39
(ii) New alarm output	9-40
10. MAINTENANCE	
10.1 Routine Inspection	1 0-1
10.2 A List of Consumable Parts	1 0-1
10.3 Maintenance	1 0-2
10.4 Replacement of Drive Cable	1 0-5
11. CALIBRATION	
① Pointer Adjustment	1 1-1
② Range Adjustment 1	1 1-4
③ Range Adjustment 2	1 1-8
④ Cold Junction Compensation Adjustment on Input Terminal Block	1 1-10
⑤ Checking Channel Data Designation	1 1-14
12. TROUBLESHOOTING	
12.1 Troubleshooting	1 2-1
(1) Troubles	1 2-1
(2) Flowchart of countermeasure for trouble	1 2-2
① Flowchart 1	1 2-2
② Flowchart 2	1 2-3
③ Flowchart 3	1 2-4
④ Flowchart 4	1 2-5
⑤ Flowchart 5	1 2-6
⑥ Flowchart 6	1 2-7
⑦ Flowchart 7	1 2-8
12.2 Self-diagnosis of Error	1 2-9
(1) Self-diagnosing items	1 2-9
(2) Error message	1 2-10
(3) Error output (FAIL)	1 2-11
(i) Normal error	1 2-11
(ii) In case of designation of power off (Option)	1 2-11



HXP	RM18mmG0002E	9頁	案	版	年	月	日	設計	承認	變更	事項	II	III	IV	V

## CONTENTS

### 13. SPECIFICATIONS

Standard Specifications	1 3 - 1
Multipoint Recorder Specifications	1 3 - 2
Standard Functions	1 3 - 3
Optional Functions	1 3 - 4
Special Optional Functions	1 3 - 5

### APPENDIXES

Appendix 1. Technical Terms	APP - 1
Appendix 2. A Cross Reference List of Display Indication	APP - 3
Appendix 3. Display	APP - 4
(1) User Mode	APP - 4
(2) Calibration Mode	APP - 5

1. UNPACKING RECORDER

1. UNPACKING RECORDER

Upon delivery of the recorder, check that all accessories are provided. Check also there is no external damage to the recorder. If an accessory is missing or there is an external damage, contact our salesman or the shop where you purchased the recorder.

1.1 Checking Accessories

The Accessories shown in Figure 1.1 are provided with the recorder. Check that all accessories are provided.




Fig. 1.1 Accessories

Chart 1.1 A List of Accessories

No.	Item	Part number	Quantity	Remarks
1	Box	H2H07827	1	To contain ②~⑦ items
2	Lubricant	H4A12290	1	
3	Wrench	HPSAA003A001	1	For M3 screw
4	Fuse	IPS0565A0105	1	
5	Chart paper	HZCAA1025AF001	1	100 equal divisions
6	Ribbon cassette	HPSR001H0005	1	
7	Clamp	H4A13299	2	For fixing panel
8	Instruction manual	HXPRM18mnG0002E	1	This manual
9	Engineering data manual	HXPRM18mnG0004E	1	

HXP <sub>RM18mm</sub> G0002E	頁	葉	版	年	月	日	設計	承認	變更	事項	II	IV
			I	95.9.25	日	日	日	日	日	日	V	

# 1. UNPACKING RECORDER

## 1.2 Checking Model and Specifications

A nameplate bearing information such as a model name is attached on the right lateral face of internal main unit. Check that the model name and code information conforms to the specifications of your order, referring to below chart. Check also that the scale plate and input codes satisfy your requirements.

Refer to 'Section 1.3 Removing Shipping Screws and Protector' how to draw the internal main unit.

# 1. UNPACKING RECORDER

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
R	M	1	8											

<p>① Model name</p> <table border="1"> <tr><td>01</td><td>1-pen recorder</td></tr> <tr><td>02</td><td>2-pen recorder</td></tr> <tr><td>03</td><td>3-pen recorder</td></tr> <tr><td>04</td><td>4-pen recorder</td></tr> <tr><td>06</td><td>6-multipoint recorder</td></tr> <tr><td>12</td><td>12-multipoint recorder</td></tr> <tr><td>24</td><td>24-multipoint recorder</td></tr> <tr><td>30</td><td>30-multipoint recorder</td></tr> </table> <p>② Construction</p> <table border="1"> <tr><td>G</td><td>Standard</td></tr> <tr><td>N</td><td>15R replacement</td></tr> </table> <p>③ Communication</p> <table border="1"> <tr><td>0</td><td>None</td></tr> <tr><td>1</td><td>RS-232C</td></tr> <tr><td>2</td><td>RS-422A</td></tr> <tr><td>9</td><td>Special</td></tr> </table> <p>④ DI/DO</p> <table border="1"> <tr><td>00</td><td>None</td><td>13</td><td>DI(5)+8-relay</td></tr> <tr><td>01</td><td>DO(52)</td><td>14</td><td>DI(5)(ARC)+8-relay</td></tr> <tr><td>02</td><td>DI(24)</td><td>15</td><td>DO(52)+DI(24)+DI(5)</td></tr> <tr><td>03</td><td>DI(5)</td><td>16</td><td>DO(52)+DI(24)+DI(5)(ARC)</td></tr> <tr><td>04</td><td>DI(5)(ARC)</td><td>17</td><td>DO(52)+DI(24)+8-relay</td></tr> <tr><td>05</td><td>8-relay</td><td>18</td><td>DO(52)+DI(5)+8-relay</td></tr> <tr><td>06</td><td>DO(52)+DI(24)</td><td>19</td><td>DO(52)+DI(5)(ARC)+8-relay</td></tr> <tr><td>07</td><td>DO(52)+DI(5)</td><td>20</td><td>DI(24)+DI(5)+8-relay</td></tr> <tr><td>08</td><td>DO(52)+DI(5)(ARC)</td><td>21</td><td>DI(24)+DI(5)(ARC)+8-relay</td></tr> <tr><td>09</td><td>DO(52)+8-relay</td><td>22</td><td>DO(52)+DI(24)+DI(5)+8-relay</td></tr> <tr><td>10</td><td>DI(24)+DI(5)</td><td>23</td><td>DO(52)+DI(24)+DI(5)(ARC)+8-relay</td></tr> <tr><td>11</td><td>DI(24)+DI(5)(ARC)</td><td>24</td><td>30-relay</td></tr> <tr><td>12</td><td>DI(24)+8-relay</td><td></td><td></td></tr> </table>	01	1-pen recorder	02	2-pen recorder	03	3-pen recorder	04	4-pen recorder	06	6-multipoint recorder	12	12-multipoint recorder	24	24-multipoint recorder	30	30-multipoint recorder	G	Standard	N	15R replacement	0	None	1	RS-232C	2	RS-422A	9	Special	00	None	13	DI(5)+8-relay	01	DO(52)	14	DI(5)(ARC)+8-relay	02	DI(24)	15	DO(52)+DI(24)+DI(5)	03	DI(5)	16	DO(52)+DI(24)+DI(5)(ARC)	04	DI(5)(ARC)	17	DO(52)+DI(24)+8-relay	05	8-relay	18	DO(52)+DI(5)+8-relay	06	DO(52)+DI(24)	19	DO(52)+DI(5)(ARC)+8-relay	07	DO(52)+DI(5)	20	DI(24)+DI(5)+8-relay	08	DO(52)+DI(5)(ARC)	21	DI(24)+DI(5)(ARC)+8-relay	09	DO(52)+8-relay	22	DO(52)+DI(24)+DI(5)+8-relay	10	DI(24)+DI(5)	23	DO(52)+DI(24)+DI(5)(ARC)+8-relay	11	DI(24)+DI(5)(ARC)	24	30-relay	12	DI(24)+8-relay			<p>⑤ Special</p> <table border="1"> <tr><td>0</td><td>None</td></tr> <tr><td>C</td><td>Electric conductivity recorder</td></tr> <tr><td>X</td><td>Hardware</td></tr> <tr><td>Y</td><td>Software</td></tr> <tr><td>Z</td><td>Software + hardware</td></tr> </table> <p>⑥ Option</p> <table border="1"> <tr><td>0</td><td>None</td></tr> <tr><td>1</td><td>Yes</td></tr> </table> <p>⑦ Quake resisting spec.</p> <table border="1"> <tr><td>A</td><td>None</td></tr> <tr><td>B</td><td>Yes</td></tr> </table> <p>⑧ Door</p> <table border="1"> <tr><td>1</td><td>N1.5(Std.)</td></tr> <tr><td>2</td><td>7.5BG4/1.5</td></tr> <tr><td>3</td><td>N4</td></tr> <tr><td>4</td><td>N7</td></tr> <tr><td>5</td><td>7.5BG6/1.5</td></tr> <tr><td>9</td><td>Special</td></tr> </table> <p>⑨ Light, front calibration, IC memory card</p> <table border="1"> <tr><td>0</td><td>None</td></tr> <tr><td>1</td><td>Light</td></tr> <tr><td>2</td><td>Front calibration</td></tr> <tr><td>3</td><td>IC memory</td></tr> <tr><td>4</td><td>Light + front calibration</td></tr> <tr><td>5</td><td>Light + IC memory</td></tr> <tr><td>6</td><td>Front calibration + IC memory</td></tr> <tr><td>7</td><td>Light + front calibration + IC memory</td></tr> </table>	0	None	C	Electric conductivity recorder	X	Hardware	Y	Software	Z	Software + hardware	0	None	1	Yes	A	None	B	Yes	1	N1.5(Std.)	2	7.5BG4/1.5	3	N4	4	N7	5	7.5BG6/1.5	9	Special	0	None	1	Light	2	Front calibration	3	IC memory	4	Light + front calibration	5	Light + IC memory	6	Front calibration + IC memory	7	Light + front calibration + IC memory
01	1-pen recorder																																																																																																																														
02	2-pen recorder																																																																																																																														
03	3-pen recorder																																																																																																																														
04	4-pen recorder																																																																																																																														
06	6-multipoint recorder																																																																																																																														
12	12-multipoint recorder																																																																																																																														
24	24-multipoint recorder																																																																																																																														
30	30-multipoint recorder																																																																																																																														
G	Standard																																																																																																																														
N	15R replacement																																																																																																																														
0	None																																																																																																																														
1	RS-232C																																																																																																																														
2	RS-422A																																																																																																																														
9	Special																																																																																																																														
00	None	13	DI(5)+8-relay																																																																																																																												
01	DO(52)	14	DI(5)(ARC)+8-relay																																																																																																																												
02	DI(24)	15	DO(52)+DI(24)+DI(5)																																																																																																																												
03	DI(5)	16	DO(52)+DI(24)+DI(5)(ARC)																																																																																																																												
04	DI(5)(ARC)	17	DO(52)+DI(24)+8-relay																																																																																																																												
05	8-relay	18	DO(52)+DI(5)+8-relay																																																																																																																												
06	DO(52)+DI(24)	19	DO(52)+DI(5)(ARC)+8-relay																																																																																																																												
07	DO(52)+DI(5)	20	DI(24)+DI(5)+8-relay																																																																																																																												
08	DO(52)+DI(5)(ARC)	21	DI(24)+DI(5)(ARC)+8-relay																																																																																																																												
09	DO(52)+8-relay	22	DO(52)+DI(24)+DI(5)+8-relay																																																																																																																												
10	DI(24)+DI(5)	23	DO(52)+DI(24)+DI(5)(ARC)+8-relay																																																																																																																												
11	DI(24)+DI(5)(ARC)	24	30-relay																																																																																																																												
12	DI(24)+8-relay																																																																																																																														
0	None																																																																																																																														
C	Electric conductivity recorder																																																																																																																														
X	Hardware																																																																																																																														
Y	Software																																																																																																																														
Z	Software + hardware																																																																																																																														
0	None																																																																																																																														
1	Yes																																																																																																																														
A	None																																																																																																																														
B	Yes																																																																																																																														
1	N1.5(Std.)																																																																																																																														
2	7.5BG4/1.5																																																																																																																														
3	N4																																																																																																																														
4	N7																																																																																																																														
5	7.5BG6/1.5																																																																																																																														
9	Special																																																																																																																														
0	None																																																																																																																														
1	Light																																																																																																																														
2	Front calibration																																																																																																																														
3	IC memory																																																																																																																														
4	Light + front calibration																																																																																																																														
5	Light + IC memory																																																																																																																														
6	Front calibration + IC memory																																																																																																																														
7	Light + front calibration + IC memory																																																																																																																														

[Notes]

1. ARC; ARCNET®
2. In case of electric conductivity recorder, 24-, 30-multipoint recorder and front calibration cannot be selected.

- 1 - 4 -

## 1. UNPACKING RECORDER

### 1.4 Temporary Storage

Remove the ribbon cassette from the main unit, and store it safely. (Refer to the Section 6.2)

The recorder has to be stored under the environment described below and when the recorder is contained in equipment as well.



When the recorder is stored under an inferior environment, its external appearance, functions, and useful life can be degraded.

#### Suitable environment

- Only a few dust and particles exist.
- None of inflammable, explosive, corrosive, gases (such as SO<sub>2</sub> and H<sub>2</sub>S) exist.
- No shock and vibration
- Free from water, moisture vapor, and high humidity (95% RH or higher)
- Free from sunshine and high temperature (50 °C or higher)
- Not extremely low temperature (-20 °C or lower)

### 1.5 Repacking Recorder

Note: Secure the main unit even when transporting the recorder contained in equipment.

#### Attaching protector for printer

- ① Remove ribbon cassette. (Refer to Section 6.2)
- ② Move the printer slowly with your fingers to center position of the main unit.
- ③ Attach a protector for the printer.




Fig. 1.4 Attaching Protector for Printer

#### Securing the main unit (by attaching the shipping screws)

Remove the shipping screws from screw holes for storage and attach the screws at the shipping screw holes, then, fix the main unit.




Fig. 1.5 Position of Shipping Screw

#### Packing

When repacking the recorder singly, use the packing box and materials for the recorder.

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

<div><div>HXP<sub>RM18mm</sub>G0002E</div><div>第15頁</div></div>						案					
版	年月日	設計	承認	變更	事項	II					IV
I	'95.9.25	山本孝夫	細井昌司			III					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

HXP <sub>RM18mm</sub> G0002E		15 頁		業	
版	年月日	設計	承認	變更	事項
I	95.9.25	山本	細井		
					IV
					V

### 3. NAMES OF COMPONENTS

### 3. NAMES OF COMPONENTS




Fig. 3.1 Name of Components (1)




Fig. 3.2 Names of Components (2)

HXP	RM18mmG0002E	16 頁	葉	版	年	月	日	設計	承認	變更	事項	II	III	IV	V







#### 4. INSTALLATION ON PANEL

##### 4.2 Outside Dimensions and Panel Cutout Dimensions


〈Front〉




〈Lateral face〉



〈Back surface〉



〈Panel cutout〉



	G MODEL(mm)	N MODEL(mm)
A	288	322
B	279	272
C	279	310.2
D	Over 360	Over 400
E	282±1	274±1
F	282±1	314±1

Fig. 4.1 Outside Dimensions and Panel Cutout Dimensions

#### 4. INSTALLATION ON PANEL

##### 4.3 Installing Recorder on Panel



For safety and main unit protection, be sure to secure the main unit with the shipping screws. (See Fig. 4.2)

- (1) Secure the main unit with the shipping screws.
- (2) Insert the recorder into the front of panel.
- (3) Insert the claws of mounting bracket into square holes at the both lateral faces of the case to fix the bracket.
- (4) Screw the carriage bolt of mounting bracket with a driver to install the recorder onto the panel. (Tighten the bolt until the recorder is jointed tightly.)
- (5) After mounting the recorder, attach the shipping screws again to the holes for storage.




Fig. 4.2 Attaching shipping screws




Fig. 4.3 Installing Recorder on Panel

#### 4. INSTALLATION ON PANEL

##### 4.4 Fixing the Rear Part of Case to Panel (Earthquake-proof Specifications) (Option)

In case of Earthquake-proof specifications, fix the rear part of case after installing the recorder on panel as per the instruction of the article 4.3.

(1) Prepare a quakeproof support (supporting angle) by yourself.

Prepare an equilateral angle steel (60mm x 60mm) with about 5 ~ 9mm thickness.

(2) The following parts are attached in case of Earthquake-proof specifications.

- Plate (1 ea.) (Part No. H3P18271)
- Bolt M10 x 20 (2 ea.) (Flat washer and spring washer are attached.)
- Screw M6 x 14 (2 ea.) (Spring washers are attached.)

(3) Fix the rear part of case using the angle (1) and the parts (2) as per the illustration of Figure 4.4.




Fig. 4.4 Fixing Rear Part of Case to Panel  
(Earthquake-proof Specifications)

## 5. WIRING

### 5. WIRING

#### 5.1 Terminal Array




Fig. 5.1 Terminal Array (Back of the Recorder)

#### 5.2 Wiring of Power Supply

##### (1) Notes on wiring of power supply

- ① Use a 600-V PVC insulated wire (JIS C3307) for the power supply.  
Use the wire with the equivalent performance or a higher-graded wire.
- ② Fix a solderless terminal with insulating sleeve (for M4) to a terminal of wire.
- ③ For connection with the earth terminal, use the 3rd category-ground resistance or over (ground resistance 100Ω or lower, minimum size of ground wire 1.6mm).
- ④ The recorder is sensitive to various noises induced electronically, particularly when the ground wire runs near the other equipment. Be sure to avoid the wiring layout close to other equipment.

##### (2) Wiring procedures

- ① Turn OFF the power switch of the recorder.
- ② Take off the clear cover of power terminal block.
- ③ Connect the wire for power supply as per the illustration of Figure 5.2.  
Connect the non-ground side of power supply with the terminal-2.
- ④ Put the clear cover onto the power terminal block.
- ⑤ Check whether the ground is made properly.




Fig. 5.2 Wiring of Power Supply

(1) Notes on input wiring


- For input wiring, be sure to avoid the induction of noise. Use the shielding wire or twisted wire in order to avoid the induction of noise in this case.
- In case of thermocouple input, use a thermocouple stand wire directly or a compensating lead wire. In this case, use of shielding input wire is recommended.
- In case of the resistive temperature detector (RTD) input, suppress the fluctuation of the three-wire resistance less than the followings:
  - In case of Pt 100, JPt 100: 50mΩ or less
  - In case of Pt 50, Cu 10Ω : 10mΩ or less

In this case, use of shielding input wire is also recommended.

- Use a shielding twisted wire to avoid the induced noise, particularly when the wire runs near a high frequency source.
- Fix a solderless terminal with insulating sleeve (for M4) to a terminal of wire.

- The wiring between the recorder and a point of measurement should be installed remotely from the power circuit (if over 25 V power or sequence circuit).
- An unused input terminal short-circuits. (In case of mV, V, thermocouple input, it short-circuits between + and -. In case of resistive temperature detector input, it short-circuits among A, B, and b.)
- In case of ground with a shielding wire, etc., it should be connected with earth terminal of the recorder.

- ①Take off the rear cover of the input terminal block.
- ②Install the input wire as per the illustration of Fig. 5.3, 5.4, and 5.5.
- ③Attach the rear cover after that.





## 5. WIRING

### 5.4 Wiring for Common Alarm Output and Fail Output

#### (1) Notes on wiring:

①The contact capacities common alarm output and fail output are as follows:

250VAC 3A Max. (Resistive load)

30VDC 3A Max. (Resistive load)

125VDC 0.5A Max. (Resistive load)

②Provide a protection network corresponding to resistive load at need, for the output terminal.

③Fix a solderless terminal with insulating sleeve (for M4) to a terminal of wire.

④Install the output wiring remotely from the input wiring.

#### (2) Wiring procedures:

Install the wiring for common alarm (COM ALM) output and fail output (FAIL) as per the illustration of Fig. 5.6

Terminal block for Common Alarm Output and Fail Output




Fig. 5.6 Wiring for Common Alarm Output and Fail Output



## 5. WIRING

### 5.5 Wiring for DI/D0 (Option)

Notes: 1. DI/D0 (option) consist of a combination of 5 contacts for DI and 8 contacts for alarm output (relay output) or 30 contacts for alarm output.

2. As to wiring for 24 contacts of DI and 52 contacts of D0, refer to a separate manual for specific matter.

#### (1) Notes on wiring for DI:

- ① Do not give an increased voltage to the DI from outside, since the generating power is set in the DI.
- ② The contact range for DI should be set as 50 VDC for difference of withstand voltage, 16 mA or over, ON resistance of  $20\Omega$  or less (including wiring resistance).
- ③ Do not use an unused terminal as a relay terminal.

Note: COM of the contact range for DI is connected at the inside of recorder.

#### (2) Notes on wiring for D0:

- ① The contact range for D0 is as follows:

250VAC 3A Max. (Resistive load)

30VDC 3A Max. (Resistive load)

125VDC 0.5A Max. (Resistive load)

- ② Provide the terminal for output at need, for a protection network corresponding to resistive load.

- ③ Fix a solderless terminal with insulating sleeve (for M4) to a terminal of wire.

- ④ Install the wiring for D0 remotely from the wiring for input.

#### (3) An example of wiring for DI:

An example of wiring for DI is shown below in Fig. 5.7.




Fig. 5.7 An Example of Wiring for DI

## 5. WIRING

### (4) Wiring procedures

Install the wiring for DI/DO as per the illustration shown in fig. 5.8 and 5.9.




Fig. 5.8 Wiring for DI (5 Contacts) and DO (8 Contacts of alarm Output)




Fig. 5.9 an Example of wiring for DO (30 Contacts of Alarm Output)

## 6. PREPARATION FOR OPERATION

### 6. PREPARATION FOR OPERATION

#### 6.1 Setting Chart Paper

Note: Use our standard chart paper for a proper recording.

- (1) Make sure that the power switch is turned 'OFF'. For replacement of chart paper, depress the power switch to 'Turn OFF' or depress **RUN/STOP** key to stop the recording function keeping the power being turned 'ON'.

Note: It may damage the printer that the chart holder is pulled down at the RUN state of recording. Be sure to take the above action before replacement of chart paper.

- (2) Open the door and remove the chart paper guide. The chart paper guide can be removed by pulling up holding its both edges with your hands.




Fig. 6.1 Removing Chart Paper Guide

- (3) Tilt the chart holder towards you by unlocking the levers at both ends of the chart holder with your hands.




Fig. 6.2 To Tilt Chart Holder Forward

- (4) Unlock the chart cover lock with your index fingers, and open the cover. Remove the chart paper from the recorder in case of replacement of the chart paper.




Fig. 6.3 Unlocking Chart Cover Lock

## 6. PREPARATION FOR OPERATION

- (5) Flip the edges through the whole chart paper.



Note: Perforations of chart paper may cause pages to hold to each other. In such case, the chart paper may not be fed smoothly.

Fig. 6.4 To Flip the Edge of Chart Paper

- (6) Unfold about three pages of chart paper. Insert the paper into the paper housing, with its square holes being located on the left side and set the edge of first page of chart paper as per the illustrated figure below.

Note: Check whether the chart paper has the perforations in this case.




Fig. 6.5 Insertion of Chart Paper

- (7) Engage the holes in the chart paper with the sprockets by bending the paper downward, then, close the chart cover to lock completely.

Secondly, pull up the chart holder by holding the levers at both edges with your hands.

Shake the levers lightly towards up and down, and left and right to check that the chart holder is being set with the main unit firmly.




Fig. 6.6 Assembly of Chart Holder

## 6. PREPARATION FOR OPERATION

(8) Set the chart paper by engaging the holes in the chart paper with the sprockets, and then, set the chart paper guide properly. In this case, check whether the holes in the chart paper is being engaged with the teeth of sprocket drum correctly.

(9) Before starting recorder operation, check whether the chart paper is fed normally. To do this, depress **FEED** key on the display keyboard keeping the power switch being turned 'ON', to feed chart paper about four to six pages.

Notes: 1. Be sure to feed chart paper about four to six pages, before starting operation.

2. If chart paper cannot be fed normally even the **FEED** key is depressed, recheck how the chart paper is set.

Reference:  $\Delta$  mark of the chart paper presser points 20 mm ahead of the plotting point. This can be used for matching time axis also.




Fig. 6.7 Sprocket Drum and Plotting Point

## 6. PREPARATION FOR OPERATION

### 6.2 Setting Ribbon Cassette

- (1) Depress the power switch to turn 'OFF' or stop the recording by depressing **RUN/STOP** key while keeping the power switch being turned 'ON'.

- (2) Draw out the main unit until it stops at the position shown in the illustrated figure below by holding the hand grip of the drawer and pushing down the lever for unlocking.




Fig. 6.8 Drawing out the Main Unit

- (3) Move the printer carefully to the center of main unit with your fingers.




Fig. 6.9 Printer and Ribbon Cassette

- (4) For replacement of ribbon cassette, remove the clamp and draw out the ribbon cassette towards the direction shown in the figure above.

Note: Be careful to replace the ribbon cassette without having any damage of the flexible printboard.

- (5) Eliminate any slack of the new ribbon cassette by turning the gear on the cassette towards arrowhead (counter-clockwise).

Note: Never turn the ribbon cassette to opposite direction of arrowhead (clockwise). Otherwise, the ribbon may not be fed.

- (6) Set the ribbon cassette by engaging the holes in the ribbon cassette with the bracket.

Note: Be careful to replace the ribbon cassette without having any damage of the flexible printboard.

- (7) Eliminate slack of the ribbon again by turning the gear on the cassette towards arrowhead.

- (8) Check whether the ribbon cassette is set correctly, and also the ribbon is set properly on the print head.

- (9) Insert the main unit into the case deeply until the main unit stops.

## 6. PREPARATION FOR OPERATION

### 6.3 Power-On



1. Check that the voltage of power conforms with the specifications of recorder and a correct ground is done, and then, turn on the power to the recorder.
2. Before turning on the power, check whether the chart paper is set the chart holder. The sprocket drum of chart holder can be damaged, when you operate the recorder without mounting the chart paper.

Open the front door and depress the power switch located lower right corner of the main unit to turn on. When power is turned on, a lamp of display comes on. You will see usual mode (User Mode) on the display screen, following the initial image (for about 7 seconds).




Fig. 6.10 Power-On

HXP <sup>31</sup> RM18mmG0002E	版	年	月	日	設計	承認	變更	事項	II	III	IV	V

## 6. PREPARATION FOR OPERATION

### 6.4 Status after Initialization

After turning on the power, LED is displayed on the display screen as the initial indication, while the initialization of the recorder is executed.

After the initialization, the recorder will become the following initial state;

Initial State:

- ①Display Mode : Auto-mode
- ②Recording - RUN/STOP : RUN
- ③Data for Printing : The data for printing, analog data, etc. before turning off the power, are all erased.
- ④Alarm & Self-diagnosis : The alarm indication, output, etc. before turning off the power, are all ceased.
- ⑤Key Lock : key lock mode

- Notes:
1. In case of breakdown of electric current, the recorder shows the above initial state, executing the initialization automatically soon after the recovery of breakdown of electric current.
  2. In the event that the power is turned off in the printing process, the printing will not be continued as mentioned in the above article ③, because of all the previous data are erased.

HXP	RM18mmG0002E	32 頁	葉	版	年	月	日	設計	承認	変	更	事	項	II	III	IV	V



## 7. DISPLAY AND KEYS

## 7. DISPLAY AND KEYS

### 7.1 Display




Fig. 7.1 Display

Chart 7.1 Display Indication

No.	Name	Meaning	Remarks
①	Mode indicator	The lamp of selected 'User Mode' is turned on.	For information about the 'User Mode', refer to the article 7.2.
②	Indicator(1)	Channel number and setting items are indicated. In case that an alarm is raised, an alarm type is indicated.	Information indicated varies from mode to mode.
③	Indicator(2)	Measured value, various setting values, date, time, etc. are indicated. When an accident (error) is raised, the error indication is made.	For information about 'Error' (self-diagnosis), refer to the article of 12.2.
④	Alarm lamp	Alarm lamp of alarm ON-channel number is turned on.	For Alarm ON, refer to the article ⑭ of Section 9.3.
⑤	Key lock lamp	In case that the key is locked, the lamp is turned on.	For information about the key-lock state, refer to article ① of Section 9.3.
⑥	RUN/STOP lamp	The lamp is on when the recorder is in RUN state.	For information about RUN/STOP, refer to the article ⑥ of Section 9.3.

## 7. DISPLAY AND KEYS

### 7.2 Functions under Usual Operation (User Modes)




Fig. 7.2 User Mode Functions

Chart 7.2 User Mode Functions:

No.	Display	Name	Function	References
①	AUTO	Auto mode	Indicates automatically the measured values of all channels sequentially.	Article ② of Section 9.3
②	MAN	Manual mode	Indicates the measured values of selected channels by depressing <input type="button" value="▽"/> <input type="button" value="△"/> keys.	Article ③ of Section 9.3
③	CLOCK	Clock mode	Indicates and changes time, day, month, and year.	Article ④ of Section 9.3
④	CHART	Chart mode	Indicates and changes the feeding speed of chart paper.	Article ⑤ of Section 9.3
⑤	PRINT	Print mode	Performs log and list printing. Generates to start comment printing. Setting the interval log printing and comment printing	Articles ⑧, ⑨, ⑩, ⑪, and ⑫ of Section 9.3
⑥	ALARM	Alarm mode	Indicates the alarm setting and sets the alarm setting points and the alarm outputs.	Articles ⑬ and ⑭ of Section 9.3

## 7. DISPLAY AND KEYS

### 7.3 Names and Functions of the Keys




Fig. 7.3 Names of Keys

Chart 7.3 Names of Keys

No.	Key	Name	Function
①	MODE	Mode key	Changes a mode sequentially AUTO → MAN → ..... → AUTO, when you depress the key.
②	PGM	Program key	Selects the input mode at the setting various parameters.
③	◀	Shift key	Changes the selecting items sequentially in reverse order at the setting various parameters. Moves the changing digit leftward mode.
④	▼ ▲	Scroll key	Sets up and changes the scroll data of the items. ▼ : Count down function of value and item. ▲ : Count up function of value and item.
⑤	ENT	Entry key	Executes the setting selected value of item at the setting various parameter. Moves the changing digit rightward at input mode.
⑥	FEED	Feed key (quick-feeding)	Feeds the chart paper quickly.
⑦	RUN/STOP	RUN/STOP key	Selects the start or stop motion of recording.

## 8. RECORD AND PRINTING

## 8. RECORD AND PRINTING

### 8.1 Multipoint Discrimination for 30 Channels

The multipoint discrimination for 30 channels can be done by this recorder using the 6-color ink ribbons and the discrimination of five types of mark.

Note: For protection of chart paper, the plot would not be made, in case of the interval between the previous plot point and the next plot point is being positioned less than 0.2 mm towards the chart paper feeding direction, or less than 0.5 mm towards the scale, in the same channel.

Chart 8.1 List of Multipoint Discrimination for 30 Channels


Mark Color	Multipoint Channel				
	•	◦	+	γ	×
Purple	Ch. 1	Ch. 7	Ch. 13	Ch. 19	Ch. 25
Red	Ch. 2	Ch. 8	Ch. 14	Ch. 20	Ch. 26
Black	Ch. 3	Ch. 9	Ch. 15	Ch. 21	Ch. 27
Green	Ch. 4	Ch. 10	Ch. 16	Ch. 22	Ch. 28
Blue	Ch. 5	Ch. 11	Ch. 17	Ch. 23	Ch. 29
Brown	Ch. 6	Ch. 12	Ch. 18	Ch. 24	Ch. 30

### 8.2 Printing

Note: Print position is 1 mm backward from plot position on the chart paper.

(1) An example of log print (12-point recorder)

Refer to the article ⑧ and ⑩ of Section 9.3 for log print.




①Time ②Channel No. ③Measured value ④Setting plot skip  
⑤Maximum, minimum, & average value (Option) ⑥Integrating value (Option)

Fig. 8.1 An Example of Log Print

## 8. RECORD AND PRINTING

### (2) An example of list print

Refer to the article ⑨ of Section 9.3 for list print.



- ①Time, day, month, and year print
- ②Setting interval log print
- ③Setting feeding speed of chart
- ④TYPE: Type of input
- ⑤RANGE: Input range
- ⑥SCAL: Scale plate '0', span point value
- ⑦UNIT: Measuring unit
- ⑧ALARM: Setting alarm
- ⑨HH, H, etc.: Setting alarm point
- ⑩RLY: Setting alarm output

Fig. 8.2 An Example of List Print

Note: Some types of input are used abbreviated words as shown below.

Type of input	Abbreviated word
PR40-20	PR4
Au-Fe	A-F
PLII	PL
JPt100	JPt
Pt100	Pt1
Pt50	Pt5
Cu10Ωat0°	Cu
Cu10Ωat25°	Cu

### (3) An example of comment print

For activation and setting of comment print, refer to the article ⑩ of Section 9.3.

Note: Comment is printed on the right hand of chart paper synchronizing with paper feed.




Fig. 8.3 An Example of Comment print

## 8. RECORD AND PRINTING

### (4) A print example of time and date

For information about printing function of time and date, refer to a separate volume "Engineering Data Manual".

Note: Synchronized printing with paper feed

Relationship between Chart Speeds and Time Print Operation:

Chart speed	Time print operation
9mm/h or slower	Printing not performed
10~29mm/h	Printed every 6 hours
30~100mm/h	Printed every 2 hours (even-numbered time)
101mm/h or faster	Printed every 1 hour

Relationship between Chart Speeds and Date Print Operation:

Chart speed	Date print operation
4mm/h or slower	Printing not performed
5mm/h or faster	Printed at designated time




Fig. 8.4 A Print Example of Time and Date

### (5) A print example of alarm mode- On/Off (Option)

Note: Synchronized printing with paper feed





Fig. 8.5 A Print Example of Alarm Mode-ON/OFF

## 8. RECORD AND PRINTING

(6) A print example of measured value of scale(option)



① Measured value at left end of scale


② Measured value at right end of scale

ex. The measured value at left end in CH 3 is 0.0kg/cm<sup>2</sup> and the measured value at right end in CH 3 is 100.0kg/cm<sup>2</sup>.

Note: Printing of the measured value of scale is synchronized with the feeding of chart paper with an interval of 60mm, except when a forced printing is activated in a process of printing.

Fig. 8.6 A Print Example of Measured Value of Scale

(7) A print example of change of range (Option)



① Range is change at range-SW1 (DI)

Note: Synchronized printing with paper feed

Fig. 8.7 A Print Example of Change of Range

## 9. RECORDING AND OPERATION (USER MODE)

## 9. RECORDING AND OPERATION (USER MODE)

### 9.1 Parameters for Setting User Modes

For user modes, the parameters shown in Chart 9.1 below can be set. In case that no specification for setting user modes is made on an order placed, the following initialization will be applied.

Refer to Section 9.2 and Section 9.3 for change of the setting procedures.

Notes: 1. All setting is maintained even after power-OFF.

After the setting is changed, the set parameters will not be returned to the initialization even if the power switch of recorder is turned OFF.

2. The items denoted 'Option' in the chart below, can be set only for the order specified such option.

Chart 9.1 Parameters for Setting User Modes

Setting Items	Setting Range	Initialization	Remarks
<b>CLOCK MODE:</b>			
Year, Month, Day, Time	Year : 1993 ~ Month : 01 ~ 12 Day : 01 ~ 31 Hour : 00 ~ 23 Minute: 00 ~ 59	Current time	
<b>CHART MODE:</b>			
Chart paper feeding speed Setting: 1st speed 2nd speed	1st/2nd 1 ~ 1800 mm/h 1 ~ 1800 mm/h	1st 30mm/h 60mm/h	
<b>PRINT MODE:</b>			
Specific interval log print Interval log print action	ON 1 (Asynchronous) ON 2 (Synchronous) OFF	ON 2	It can be set only for 8 hr interval or over.
Interval log print space	10,20,30 min. 1,2,3,4,6,8, 12,24 hour interval	6 hour	
Starting time of printing	0 ~ 23	—	
Max., Min., Ave. setting print (Option)	ON OFF	OFF	
Note: Set for each channel. Setting integrating print (Option)	ON OFF	OFF	

(To be continued to next page)



## 9. RECORDING AND OPERATION (USER MODE)

(To be continued from previous page)

Setting Item	Setting Range	Initialization	Remarks
Comment print Comment data No.1 ~ No.5 (5 types) 16 characters for each	ASCII code 20H - 7FH	Whole data 20H	H stands for hexa-code.
Setting plot skipping  Note: Set for each channel.	ON - plotting OFF - no plotting	For all channels ON	
<b>ALARM MODE:</b>			
Setting alarm point Note: The following alarm actions for each channel can be set. (Alarm type: 6 types) HH alarm H alarm L alarm LL alarm Rate of change alarm (RH) Rate of change alarm (RL) (Parameter for detective) Detective interval for rate of change(tc)  Setting new alarm mode (Option) Note: Set for each channel.	-19999 ~ 99999 (Decimal point, setting point units conform with setting engineering data.)  1 ~ 99 sampling Setting number of sampling per channel. 1 sampling: 5.0 sec./ch. × number of ch. (See footnote of the chart.)  ON for alarm OFF for no alarm	For all channels: HH : 0. 0 H : 0. 0 L : 0. 0 LL : 0. 0 RH : 0. 0 RL : 0. 0  tc : 1  OFF	Changing range specifications (Option) : OK for each range.
Setting alarm output Setting of 2-outputs for each alarm type of each channel can be made. Numbers of channel (30) × Alarm type (6)	00 ~ 60  Note: 00: No relay output No detective action in case two points are 00. 01 ~ 60: OK for indication & relay output	00, 00	Changing range specifications (Option) : OK for each range. (No detective action)  (Relay output: option)

Note: 2.5 sec.-plotting : 2.5 sec/ch  
5 sec.-plotting : 5 sec/ch  
10 sec.-plotting : 10 sec/ch

## 9. RECORDING AND OPERATION (USER MODE)

### 9.2 A Summary Chart of Recording and Operation (User Mode)

Refer to Section 9.3 as to the procedures.

Refer to Section 9.1 as to the parameters for setting.

Chart 9.2 A Summary Chart of Recording and Operation

Operation	User Mode	Reference
To set/Release - Key lock		9.3 - ①
To indicate measured value by auto mode.	AUTO mode	9.3 - ②
To indicate measured value by manual mode.	MANUAL mode	9.3 - ③
To indicate year, month, day, and time.	CLOCK mode	9.3 - ④
To set paper feed of chart paper and its indication.	CHART mode	9.3 - ⑤
To change paper feed RUN/STOP.		9.3 - ⑥
To feed(FEED) chart paper quickly.		9.3 - ⑦
To execute log print.	PRINT mode	9.3 - ⑧
To execute list print.	PRINT mode	9.3 - ⑨
To set interval log print.	PRINT mode	9.3 - ⑩
To set and start up comment print.	PRINT mode	9.3 - ⑪
To set plot skipping function.	PRINT mode	9.3 - ⑫
To set alarm functions.	ALARM mode	9.3 - ⑬
To check alarm ON.		9.3 - ⑭
To execute resetting new alarm function. (Option)	ALARM mode	9.3 - ⑮

### 9.3 Recording and Operation Procedures

① Locking and unlocking key

IV V

--	--	--

111

---

1	2
---	---



項	II
	II

毒

- |   |   |    |   |
|---|---|----|---|
| 更 | 變 | 承認 | 細 |
|---|---|----|---|

年月日	95.9.25
-----	---------

HXP	RM18mnG0002E	44頁	葉	版	年	月	日	設計	承認	變更	事項	II	III	IV	V

## 9. RECORDING AND OPERATION (USER MODE)

### ② Indication of measured value by auto mode (Auto Mode)

In this mode, the measured value for each channel is indicated sequentially, and the indication is changed at plot interval.

#### (1) Selection of Auto Mode

Depress **MODE** key to turn on the auto mode lamp of the indicator, then the indication of measured value is changed at the interval of plot automatically.

As to the indication of 'Alarm ON' or 'ERROR', refer to the article ⑭ Checking 'Alarm ON', ⑮ Execution of Resetting New Alarm, and Section 11.1.

- Notes: 1. For the channel set the plot skipping, the measured value is not indicated.
2. In the event that 'Display OFF'-function (option) is being set 'ON', the measured value is not indicated.

### ③ Indication of measured value by manual mode (Manual Mode)

To indicate the selected fixed channel.

For 'Alarm ON Mode', refer to the articles ⑭ Checking Alarm ON', and ⑮ Execution of Resetting New Alarm'.

#### (1) Selection of Manual Mode

Depress **MODE** key to turn on 'MAN lamp' of the mode indicator.

Select the indication channel by operating **▽** **△** keys.

Depress **ENT** key to select Manual Mode 2.

# 9. RECORDING AND OPERATION (USER MODE)

## (2) Manual Modes 1 and 2

Function		Manual Mode 1	Manual Mode 2
Display	Indicator (1)	Indication of Channel No.	Blinking Channel No.
	Indicator (2)	To indicate the measured value, but indicate "SE P" for Plot Skip Selection channel.	
Plotting		Performed	Not performed
Checking alarm		Performed	Output for indication channel only
Interval log print		Performed	Not performed
Self-diagnosis		Performed	Not performed
Sampling cycle of indication		Synchronizing with the plot	0.5 sec. cycle


9. RECORDING AND OPERATION (USER MODE)

④ Setting indication of time, day, month, year (Clock Mode)

In CLOCK mode, current time, day, month, and year are indicated on the indicator-(2) as the illustration below. You can change above also.  
(Refer to the article (2).)

(1) Indication of time, day, month, year

Depress **MODE** key, to turn on CLOCK lamp in the mode indicator, and then, current time, day, month, and year (A.D.) are indicated.



The followings are to be indicated on the indicator-(1)

- CL : Clock
- E : Time
- d : Date
- Y : Year(A.D.)

Fig. 9.1 Indicator Screen in Clock Mode


## 9. RECORDING AND OPERATION (USER MODE)

### (2) Changing of time, day, month, year

Depress **MODE** key to turn on CLOCK lamp of the mode indicator and to indicate current time.

Select a digit to be changed (time, day, month, and year) by depressing

**▽** **△** key to move a blinking cursor to it.



#### [ Manipulation of Key ]

**□** : point of input (a blinking cursor)      Selection of figure: **▽** **△**

Moving to select a digit:      Depress **ENT** key to move rightward (to select input point).

Depress **◀** to move leftward (moving only).

Input Mode-Off: Depress **MODE** key (to move to 'Chart Mode')

or depress **ENT** key setting the blinking cursor at the right-end digit.

Fig. 9.2 Change of Time

## 9. RECORDING AND OPERATION (USER MODE)

### ⑤ Setting and indication of feeding speed of chart paper (Chart Mode)

In setting feeding speed of chart paper, the setting of '1st speed' or the setting of '2nd speed' can be selected. For indication of each feeding speed, refer to the article (1), and refer to the article (2) for its setting.

#### (1) Indication of feeding speed of chart paper

Depress **MODE** key to turn on 'CHART' lamp of the mode indicator, then, the feeding speed of chart paper is indicated.

Each item is indicated  
by depressing

key.




Fig. 9.3 Indication of Chart Mode

Note: For protection of chart paper, the plot would not be made in case of the interval between the previous plot point and the next plot point is being positioned less than 0.2 mm towards the chart paper feeding direction, or less than 0.5 mm towards the scale, in the same channel. It requires the following chart paper feeding speed to plot with the whole points.

Plotting Interval	Chart Paper Feeding Speed
2.5 sec. interval plot	Over 30 mm/h
5 sec. interval plot	Over 15 mm/h
10 sec. interval plot	Over 10 mm/h




## 9. RECORDING AND OPERATION (USER MODE)

### (2) Changing of setting for feeding speed of chart paper

Note: The changing method of paper speed at delivery time, is set as the changing is being made through DI. Follow the steps illustrated below, after changing of the changing method of paper feeding speed to the manipulating key method referring to the Engineering Data manual.

Depress **MODE** key to indicate the paper feeding speed as described in (1), and then, depress **PGM** key.

An example of changing the paper feeding speed from '1st' to '2nd' is shown below.



#### [ Manipulation of Key ]

: Point of input  
(a blinking cursor)

Selection of item : **▽** **△**

Determination of input : **ENT**

Input Mode - OFF: Depress **MODE** key (to move to 'Print Mode')  
(forced release)

Fig. 9.4 Change of Feeding Speed of Chart Paper

## 9. RECORDING AND OPERATION (USER MODE)


### (3) Changing feeding speed (1st, 2nd)

Allowable range for setting: 1 ~ 1800 mm/h

An example of changing the set value(1st) of paper feeding speed from 60 mm/h to 30 mm/h, is illustrated below.

Depress  $\nabla$   $\triangle$  key to select the indication of paper feeding speed value (1st, 2nd) to be changed as described in the article (1).

Depress  $\boxed{\text{PGM}}$  key when the paper feeding speed value is indicated.



#### [ Manipulation of Key ]

$\boxed{\phantom{00}}$  : Point of input (a blinking cursor)

Selection of figure:  $\nabla$   $\triangle$

Moving to select a digit:

Depress  $\boxed{\text{ENT}}$  key to move rightward (to select input point).

Depress  $\boxed{\triangleleft}$  key to move leftward (moving only).

Input Mode-OFF: Depress  $\boxed{\text{MODE}}$  key (to move to PRINT Mode or  $\boxed{\text{ENT}}$  key setting the blinking cursor at the left-end digit.

Fig. 9.5 Changing the 1st Feeding Speed

## 9. RECORDING AND OPERATION (USER MODE)

### ⑥ Changing recording function - RUN/STOP

Start or stop of recording function is selected alternately by depressing

**RUN/STOP** key. Also RUN/STOP lamp is turned on/off likewise.

RUN/STOP lamp ON ; 'RUN' State of recording

OFF; 'STOP' State of stopping

State of stopping In this state, recording and sampling of data link are not executed. The value immediate before stopping is retained and indicated.

### ⑦ Quick-feeding (FEED) of chart paper

Depress **FEED** key.

Quick-feeding of chart paper goes on while **FEED** key is being depressed.

## 9. RECORDING AND OPERATION (USER MODE)

### ⑧ Log print (Print Mode)

#### (1) Print mode

In this mode, log print, list print (output print of parameter established), comment print can be set to go on.

Setting of interval log print and comment print are enabled.

Note: Each print function is enabled only when the recording function is in 'RUN' state.

#### (2) Selection of print mode

Depress **MODE** key to turn on PRINT lamp of the mode indicator, then, the followings are indicated on the indicators(1), and(2).




Fig.9.6 Indication in Print Mode

## 9. RECORDING AND OPERATION (USER MODE)

### (3) Printing priority

The recorder has the printing priority described below. When a print operation is requested, that has a higher priority than the current print operation, the print operation with the higher priority is performed first, suspending the current print operation. Then the suspended print operation is resumed.

Priority: ←higher lower→

List print > Alarm ON print > Alarm OFF print > Log print > Comment print  
> Date print > Time print

Note: Several comment prints at one time can not be executed.

### (4) Log print

Depress **ENT** key to start log print when 'Log'/'Print' indications are shown on both indicators respectively. As to an example of log print, refer to Chapter 8.

Indicator(1)

L O G

Indicator(2)

P r i n t

Both of indicators, (1) and (2) are blinking while printing is executed.

Fig. 9.7 Execution of Log Print

- Notes: 1. Printing is enabled only when the function is in the RUN state.  
2. Chart paper is fed forcibly, since log print is not synchronized with paper feed.  
3. Forced stop of log print  
Depress **RUN/STOP** key to interrupt log print operation, then, the print operation is stopped and simultaneously, other waiting requests for print are erased also.

## 9. RECORDING AND OPERATION (USER MODE)

### ⑨ List print (Print Mode)

For print mode, refer to Section ⑧ Log print.

Refer to Chapter 8 for an example of list print.

Depress **MODE** key to turn on PRINT lamp of the mode indicator for selection of

Print Mode. Operate **△** **▽** key for list print selection (Fig. 9.8.).

Depress **ENT** key when list print selection is indicated, then list print is executed.

Indicator (1)

**L I S T**

Indicator (2)

**P R I N T**

Both of indicators, (1) and (2) are blinking while printing is executed.

Fig. 9.8 Execution of List Print

Notes: 1. Printing is enabled only when the function is in the RUN state.

2. Chart paper is fed forcibly, since list print is not synchronized with paper feed.

3. Forced stop of list print

Depress **RUN/STOP** key to interrupt list operation, then, the print operation is stopped and simultaneously, other waiting requests for print are erased also.

## 9. RECORDING AND OPERATION (USER MODE)

### ⑩ Setting interval log print (Print Mode)

For print mode, refer to Section ⑧ Log Print.

[Note] Life of ribbon will be shorter according to logging print times.

For more information, refer to Chapter 10.

#### (1) Setting interval log print

Depress **MODE** key to turn on PRINT lamp of the mode indicator.

Operate **▽** **△** key for interval log print selection (Fig.9.9).

Depress **ENT** key to indicate setting of interval log print function.

Depress **▽** key to indicate setting of interval log print.




Fig. 9.9 Setting Log Print

For details of setting, refer to the article " (3) Interval Log Print Function and Printing Interval"

## 9. RECORDING AND OPERATION (USER MODE)


### (2) Changing interval log print function

Operate  $\nabla$   $\Delta$  key for interval log print selection like the manner described in the article (1).

Depress  $\boxed{\text{PGM}}$  key to get into Input Mode.

Operate  $\nabla$   $\Delta$  keys to select print function.

Depress  $\boxed{\text{ENT}}$  key to execute.



#### [ Manipulation of key ]

$\boxed{\phantom{00}}$  : Point of input (a blinking cursor)

Selection of item:  $\nabla$   $\Delta$

Determination of input:  $\boxed{\text{ENT}}$

Input Mode - OFF: Depress  $\boxed{\text{MODE}}$  key (to go to 'Alarm Mode')

Fig. 9.10 Changing the Set Interval Log Print



## 9. RECORDING AND OPERATION (USER MODE)

### (3) Interval log print function and printing interval

- i) There are two types of interval log print according to the feeding method of chart paper, one is 'Forced Paper Feed Method' and the other one is 'Synchronized Paper Feed Method'.

Chart 9.3 Interval Log Print

Indicator (2)	Title of Indication	Function
ON 1	Execution of interval log print (Forced feeding of chart paper)	To execute interval log print. After the start of printing, the compulsory line feed and paper feed are executed according to the printing format. Analog print will be suspended at this time.
ON 2	Execution of interval log print (Synchronized feeding of chart paper)	To execute log print. Analog print will not be suspended, since the printing is executed according to the set chart paper feeding speed. It requires the paper feeding with a certain speed or more (see the article ii)) to print log properly.
OFF	Interval log print OFF	No log print

## 9. RECORDING AND OPERATION (USER MODE)

### ii) Printing interval of interval log print

Interval log print is executed synchronizing with the built-in clock. At the mode of "ON2" (synchronized paper feed), it requires the minimum paper feeding speed shown in the below chart to print log properly.

Chart 9.4 Printing Interval of Log Print

Indicator (2)	Printing Interval	Designation of start time	Min.feeding speed of chart paper
10分	10-min. interval, every hour 00 10 20 30 40 50 min.,	Not applicable	7 2mm/h
20分	20-min. interval, every hour 00 20 40 min.,	Not applicable	3 6mm/h
30分	30-min. interval, every hour 00 30 min.,	Not applicable	2 4mm/h
1H	1-hr. interval, everyhour,	Not applicable	1 2mm/h
2H	2-hr. interval, 00 02 04.....22 hrs.,	Not applicable	6mm/h
3H	3-hr. interval, 00 03 06.....21 hrs.,	Not applicable	4mm/h
4H	4-hr. interval, 00 04 08.....20 hrs.,	Not applicable	3mm/h
6H	6-hr. interval, 00 06 12.....18 hrs.,	Not applicable	2mm/h
8H00	8-hr. interval, start time, start time + 8hrs., start time + 16hrs.,	Applicable	2mm/h
12H00	12-hr.interval,start time,start time+12hrs.,	Applicable	1 mm/h
24H00	24-hr.interval, every day start time,	Applicable	1 mm/h

Note: In case of the printing with maximum, minimum, and average, value specifications (option); or integrating value printing specifications(option); the minimum feeding speed of chart paper needs to be set with a larger setting value than shown in Chart9.4, because of increasing of the volume of print.

## 9. RECORDING AND OPERATION (USER MODE)


### (4) Changing of printing interval of log print

Operate   key for selection of printing interval for interval log print like the article (1).

Depress  key.

For details of setting, refer to the article '(3) Interval Log Function and Printing Interval'.

In the event that printing intervals are set like 8-hr., 12-hr., and 24-hr., interval; starting time has to be set. Refer to next page in this case.



#### [ Manipulation of key ]

: Point of input  
(a blinking cursor)

Selection of item :

Determination of input:

Input Mode-OFF: Depress  key (to go to Alarm Mode)


Fig. 9.11 Changing of Printing Interval of Log Print

## 9. RECORDING AND OPERATION (USER MODE)


In the event that printing intervals are set just as 8-hr., 12-hr., and 24-hr., interval, starting time has to be set.



When **ENT** key is depressed in the manipulation of keys in the same manner described in previous page, the designated starting time of print is blinking on the display of indicator (2).

Note: Starting time of printing can be set at every hour.




### [ Manipulation of Keys ]

 : Point of input  
(a blinking cursor)

Selection of figure:  

Moving to a digit to be changed:

Depress **ENT** key to move  
rightward (to select input  
point).

Depress  key to move  
leftward (moving only).

Input Mode Off: Depress **MODE** key (to move Alarm Mode) or  
(release)

**ENT** key setting the blinking cursor at the right-  
end digit.

Fig. 9.12 Changing of Starting Time of Printing

## 9. RECORDING AND OPERATION (USER MODE)

### (5) Setting of printing with maximum, minimum, and average value (Option)

Select ON/OFF of printing function with maximum, minimum, and average values for each channel at log print.

Select setting screen for printing with maximum, minimum, and average values like the manner described in the article(1).




Fig. 9.13 Setting of Printing with Max., Min., & Ave. Values

### (6) Setting of printing with integrating value (Option)

Select ON/OFF on log print with integrating value by DI.

Select setting of printing with integrating value following the article (1).




Fig. 9.14 Setting of Printing with Integrating Value

## 9. RECORDING AND OPERATION (USER MODE)

### ① Setting comment print and its printing (Print Mode)

For Print Mode, refer to the article '⑧ Log Printing (Print Mode)'.

For an example of comment print, refer to the article (3) of Section 8.2.

Note: The comments of No.1 to 5, and 16 characters for each comment can be set.

#### (1) Comment printing

Depress **MODE** key to turn on PRINT lamp of the mode indicator, and select Print Mode.

Select the setting item of comment print by operating **▽** **△** key.




Fig. 9.15 Setting Comment Print


Note: In the event that comment print is executed at Print Mode, chart paper is feeded forcibly. In case of comment printing by DI (option), printing is made synchronizing with chart paper feeding.

## 9. RECORDING AND OPERATION (USER MODE)

### (2) Checking comment data

Depress **MODE** key to turn on PRINT lamp of the mode indicator, and select Print Mode.

Select the setting item of comment print by operating **▽** **△** key.



#### [ Manipulation of key ]

Depress **MODE** key at Input Mode (LED is blinking) to go to Alarm Mode and to release Input Mode.

For the characters, refer to Chart 9.5 Character Codes.

Fig. 9.16 Checking Character Codes

## 9. RECORDING AND OPERATION (USER MODE)

### (3) A list of character codes

Note: The character is set by ASCII code.

Chart 9.5 Character Codes

High order →

low order ↓

	2	3	4	5	6	7
0		0	@	P		p
1	!	1	A	Q	a	q
2	"	2	B	R	b	r
3	#	3	C	S	c	s
4	\$	4	D	T	d	t
5	%	5	E	U	e	u
6	&	6	F	V	f	v
7	'	7	G	W	g	w
8	(	8	H	X	h	x
9	)	9	I	Y	i	y
A	*	:	J	Z	j	z
B	+	;	K	[	k	{
C	,	<	L	¥	l	
D	-	=	M	]	m	}
E	.	>	N	^	n	~
F	-	?	O	_	o	

ex) You can locate "A" at crossing point of the vertical 4 with the across 1.




## 9. RECORDING AND OPERATION (USER MODE)

### (4) Changing comment data

Select character number at Character Mode like the manner described in the article (2), by operating  $\nabla$   $\Delta$  key.

Depress **PGM** key to go to Changing Mode of Character.



#### [ Manipulation of Key ]

**■** : Point of input (a blinking cursor)

Selection of figure or item:  $\nabla$   $\Delta$

Moving to select a digit: Depress **ENT** key to move rightward (to select input point).

Depress  $\triangleleft$  key to move leftward (moving only).

Moving to next character No.: Depress **ENT** key for input, setting the blinking cursor at right-end digit.

Select character No. at Character Mode by operating  $\nabla$   $\Delta$  key.

Input Mode - Off: Depress **MODE** key to go to Alarm Mode. (release)

Return to Character Mode by depressing **PGM** key.

Fig. 9.17 Changing Comment Data

HXP	RM18mmG0002E	頁	業	版	年	月	日	設計	承認	變更	事項	II	III	IV	V

9. RECORDING AND OPERATION (USER MODE)

⑫ Setting plot skip function (Print Mode)

For Print Mode, refer to the article '⑧ Printing Log (Print Mode)'.

(1) Plot skip function

In order to skip the plotting and the indication of measured value at certain channel, set plot function OFF at the Plot Skip Mode.

The functions of the set channel are as follows;


- No plotting.
- The measured value is not indicated at Auto Mode or Manual Mode.
- No alarm detection is made.
- The measured value is indicated as "\*" under the log print.

## 9. RECORDING AND OPERATION (USER MODE)

### (2) Setting plotting OFF

Select the setting mode of Plot Skip according to the article '(2) of ⑧.

Selection of Print Mode'



#### [ Manipulation of Key ]

: Point of input (a blinking cursor)

Selection of item: **▽** **△**

Moving to select a digit for input: **ENT**

Input Mode-Off: Depress **MODE** key to move to (Alarm Mode). (release)

Setting of skipping for all channel cannot be made. An error message is indicated.

**P r 0 3**      **E**   **o F F**

← error message

Fig. 9.18 Setting of Plotting OFF

## 9. RECORDING AND OPERATION (USER MODE)

### ⑬ Setting alarm function (Alarm Mode)

#### (1) Alarm function

Setting of the following alarm modes and alarm outputs can be made.


In case of the changeable range specifications (option), the above setting can be made for each range.


Setting Alarm Mode: 7 modes can be set. (See Chart 9.6.)

Alarm (output): For output, two modes can be set for each alarm mode.

(For setting, refer to the article (2).)

Chart 9.6 A summary list of Setting of Alarm Modes

Indicator(1) (ex.channel 1)	Alarm Mode	Function	Setting Range
<input type="checkbox"/> HH	High-High alarm	When a measured value exceeds an alarm setting point.	-19999~99999
H	High alarm		
LL	Low-Low alarm	When a measured value is lower than alarm setting point.	
L	Low alarm		
RH	Rate of change alarm(RH)	<p>In case of + deviation in the measured value, arises on the detective interval for rate of change (tc) to be set in the figure shown below.</p> <p>Measured value</p>  <p>BH</p> <p>Sampling</p> <p>Detective interval for rate of change (tc)</p>	Note: Decimal point is set based on the setting value of Engineering Mode
RL	(RL)	<p>In case of - deviation in the measured value, arises on the detective interval for rate change, reverse to RH case.</p>	
EC	Detective interval for rate of change	Setting a sampling interval of rate of change alarm	1~99 sample (1 sampling: plot interval x numbers of channel)



## 9. RECORDING AND OPERATION (USER MODE)

### (2) Designation of D0 number

Set D0 number for output when an alarm is occurred.

Notes for setting:

- 1) The following D0 are available as optional functions.  
Alarm output: 8 points (D0 No.01~08), D0: 52 points (D0 No. 09~60)  
60 points in total, or alarm output: 30points (D0 No.01~30).
- 2) Although you will be able to set D0 number which is not designated at time of placing an order, alarm output cannot be made in that case.
- 3) In the setting of alarm output, two alarm points can be set for each alarm mode.
- 4) In case only one point of alarm output is being set, one of the setting points needs to be set as " 0 0 ".
- 5) In case of no detection of alarm is made, both of D0 numbers need to be set as "0 0".
- 6) The same D0 number can be set in different alarm mode or different channel.
- 7) Common Alarm (COM.ALM) at occurrence of alarm is output when D0 number is designated.
- 8) The alarm output is made synchronizing with the plotting.


### (3) Display screen of alarm mode

The alarm mode consists of the followings.


The following figures are the initial display screens for each alarm mode selected.

版	年	月	日	設計	承認	變更	事項	II	III	IV	V
I	95	9	25	出	山	山	山				
HXP RM18mmG0002E 69 頁 葉											

## 9. RECORDING AND OPERATION (USER MODE)

Note: To return to previous display screen by depressing  key.

Alarm lamp is turned on by depressing **MODE** key.



Note:

Alarm mode mode  
Indication of new alarm reset  
ALF -ESEE

In case of designating New Alarm Function (option), the indication shown in the left figure is indicated at an initial indication of alarm mode. See the article 15. of Sec. 9.3

Fig. 9.19 Display Screen of Alarm Mode

## 9. RECORDING AND OPERATION (USER MODE)

### (4) Checking alarm setting

There are two methods in checking alarm setting point and setting alarm output, as follows;

(a) To indicate each setting automatically in the indicators (1) and (2).

Refer to '(i) Auto-checking of Alarm setting' described below.

(b) To print out each setting with the list print function.

Refer to ⑨. 'List Print (Print Mode)'.

(i) Auto-checking of alarm setting:

Setting of, each alarm point and alarm output are indicated automatically in the indicators (1) and (2).




Fig. 9.20 Auto-Checking of Alarm Setting

## 9. RECORDING AND OPERATION (USER MODE)

### (5) Changing alarm mode setting

Set various alarm points.

For various alarm setting, refer to Chart 9.6.

#### (i) Selection of alarm setting point for change:




Fig. 9.21 Selection of Alarm Setting Point for Change




## 9. RECORDING AND OPERATION (USER MODE)

### (ii) Changing alarm setting point:

An example of Changing HH-alarm setting point in the channel 01, from 10000 to 5000 is shown below.

Call the alarm mode like the manner described in the article (i), to indicate the alarm setting point to be changed.



#### [ Manipulation of Key ]

--

 : Input item  
(a blinking cursor)

Selection of item: 

▽
---

△
---

Moving to select a digit: Depress 

ENT
-----

 key to move rightward (to select input item).

Depress 

◀
---

 key to move leftward (moving only).

Input Mode - Off : Depress 

MODE
------

 key (to move to Auto Mode) or depress 

ENT
-----

 key setting the blinking cursor at right-end digit.


Fig. 9.22 Changing Alarm Setting Point

## 9. RECORDING AND OPERATION (USER MODE)

### (6) Selection new alarm function On/OFF (Option)

Indication of setting new alarm ON/OFF function is indicated next to the interval indication (  $\square\square$  ) of detecting change of rate, of the alarm point setting indication for each channel.

Select alarm setting mode as per Fig. 9.19.



Select ON/OFF according to 'Manipulation of Key' shown below.




Fig. 9.23 Selection of New Alarm ON/OFF

[illegible]

(7) Changing alarm output (DO) number setting

Setting DO number for alarm output.

For setting output (D0), refer to the article (2).

(i) Selection of alarm (D0) setting for change

Note: Depress **MODE** key to go out Alarm Mode.





Fig. 9.24 Selection of Alarm (D0) Setting for Change

## 9. RECORDING AND OPERATION (USER MODE)

### (ii) Changing alarm output (DO) number setting:

An example of change of setting alarm output from DO No. 10 to 20 and 09, is shown below;

Select the set Alarm Output for change following to the procedures of the article (1).




#### [ Manipulation of Key ]

--

 : Input point (a blinking cursor)

Selection of item:



Moving to

Select a digit: Depress **ENT** key

to move rightward (to select input item).

Depress 

◀
---

 key to

move leftward (moving only).

Input Mode - Off: Depress **MODE** key (to go to Auto Mode) or

depress **ENT** key setting the blinking cursor

at right-end digit.

Fig. 9.25 Change of the set Alarm Output

## 9. RECORDING AND OPERATION (USER MODE)

### ⑭ Checking state of alarm-ON

The following alarm indication and alarm output are made according to the set alarm value at Alarm Mode.

Notes: 1. In case of the specifications of Alarm Print and Alarm Recovery Print (option), printing is executed. For the print examples, see article (5) of Section 8.2.

2. In case of the specifications of New Alarm Function (option), alarm indication and output differ from the above.

Refer to the 'article ⑮ Execution of New Alarm Reset'.

#### (1) Indication of alarm

- Alarm lamp of the channel where an alarm arises, is turned on.
- The alarm modes (HH-Alarm, LL-Alarm, etc.) are indicated at right hand of the indicated channel No. on the indicator (1).
- When the alarms arose in a channel, the alarm modes arisen, are indicated in sequence automatically.




Fig. 9.26 Indication of HH-Alarm-On at Channel No. 01

#### (2) Alarm output

The outputs are made for the set number D0 and Common Alarm Output during Alarm-On. For the details of setting, refer to the article ⑬-(2) of Section 9.3.

#### (3) Checking of the set alarm point and alarm output

Checking of the set point of alarm and the set output of alarm in the state of Alarm-On, can be done as follows:

Check them at Auto-Checking of Alarm Setting function in Alarm Mode.

Execute List Print.

Refer to the article ⑬-(5) of Section 9.3 "Changing Alarm Mode Setting".

## 9. RECORDING AND OPERATION (USER MODE)

### ⑤ Execution of new alarm reset (Alarm Mode)

Note: New alarm function is optional.

#### (1) Execution of new alarm reset

New alarm reset can be executed by the following two methods.

① Depress **ENT** key at the alarm indication state in Auto Mode.

② Depress **ENT** key to select New Alarm Reset in Alarm Mode.




Fig. 9.27 Execution of New Alarm Reset

#### (2) New alarm reset function

The functions of alarm On are as follows.

##### (i) Indication

- Alarm lamp of the channel-alarm on, is blinking.
- In Auto Mode, only the channel-alarm on is indicated. The measured value on the alarm on state is maintained (in case of multi-occurrence of alarm, the indication is made by switching to the automatic indication).
- In the event that New Alarm Reset is executed before alarm recovery, alarm indication will be like the case without New Alarm function. (Refer to the preceding page.)
- After alarm recovery, alarm indication is maintained until New Alarm Reset is executed.

## 9. RECORDING AND OPERATION (USER MODE)

### (ii) New alarm output

Note: The relay output time and the output relay number should be set in Engineering Mode. Refer to a separate volume of manual 'Engineering Data Manual'.

Output is made for a period of the setting time, and the setting relay.

In the event that an alarm is recovered during the setting time of relay output:

..... The output is maintained from the alarm-ON until the relay output time set, expires.

In case of execution of New Alarm Reset during the setting time of relay output:

..... The output is made just as the case without a New Alarm function.

(Refer to the article ⑭-(2) of Section 9.3.)

HXP	RM18mn	G0002E	79	頁	葉	版	年月日	設計	承認	變更	事項	II																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													</
-----	--------	--------	----	---	---	---	-----	----	----	----	----	----	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

## 10. MAINTENANCE

### 10. MAINTENANCE

#### 10.1 Routine Inspection

Routinely check the items listed below. If there is something wrong with the recorder, refer to Chapter 12 Trouble Shooting.

(1) Is the pointer deflected over the scale?

(2) Are recording and indication normal?

- Is there any major difference between the displayed and the analog recorded values?
- Is there any unusual analog record?
- Is analog record print faint?
- Are color of analog record and marks normal?
- Is printing operation normal?

(3) Is chart paper fed normally?

- Is chart paper folded normally?
- Is there any broken hole of chart paper feed?
- Is chart paper fed properly?

(4) Is abnormal sound made?

#### 10.2 A List of Consumable Parts

Chart 10.1 A List of Consumable Parts

NO.	Name of Consumable Part	Part Number	Remarks
1	Chart paper	HZCAA1025AF001	100 equal divisions
2	Ribbon cassette	HPSR001H0005	
3	Lubricant	H4A12290	Launa 40 from Nippon Oil Co.or equivalent
4	Drive cable	HPSU018B10	
5	Fuse	IPS0565A0105	2A



## 10. MAINTENANCE

### 10.3 Maintenance


Chart 10.2 A Summary List of Maintenance

Maintenance Item	Procedure
Chart paper	<p>(1) When the remaining chart paper become a few length, a printed red mark, at the right of chart paper, prompting replacement of chart paper, appears. Replace chart paper immediately.</p> <p>Note: 1. If print operation is continued with no chart paper loaded, the sprocket drum can be stained with ink or both of printer and sprocket drum can be damaged, resulting in a failure of the recorder. Be sure to use the recorder with chart paper loaded.</p> <p>2. Be sure to use our standard chart paper to ensure normal feeding of chart paper.</p> <p>References: 1. A set of chart paper is 23 m long. 2. The remaining volume of chart paper can be monitored through a window set on right lateral face of the main unit, after pulling out the main unit.</p>
Ribbon cassette	<p>(1) Printing with a ribbon gets gradually lighter, so it is recommended that the ribbon cassette be replaced at an earlier stage for clear printing.</p> <p>(2) Use a ribbon cassette purchased within one year, its useful life gets shorter by the evaporation of ink.</p> <p>Guideline for replacement:</p> <ul style="list-style-type: none"> <li>• Printing usage for about 3 rolls of chart paper (usually 3 months for continuous operation) under the normal circumstances.</li> <li>• In case of a pause of operation, approximate 6 months after unpacking of ribbon cassette.</li> </ul> <p>Note: Do not use the ribbon which fiber is scraped or ravelled. The ribbon subject to be replaced in shorter term according to logging print times. Refer to "10-4" for details.</p>
Oiling	<p>For a use of the recorder in good condition at all times, check oil shortage of the mechanical moving parts and oil the recorder as required.</p> <p>Notes: 1. Oil the recorder periodically at intervals of about 6 months. 2. Remove any build up of dirt before oiling. 3. Apply just one or two drips of oil to prevent dripping, and remove any excessive oil.</p> <p>Oiling spots:</p> <ol style="list-style-type: none"> <li>Printer spindle (every 3 months)</li> <li>Grooved shaft (every 3 months)</li> <li>Ribbon rocking gear and bearing (every 3 months)</li> <li>Sprocket drum bearing (every year)</li> </ol> <div data-bbox="1005 1568 1276 1825"> <p>The diagram shows a side view of the recorder's main unit with its cover removed. Four specific points are labeled with letters: 'a' points to the printer spindle at the top; 'b' points to a grooved shaft in the middle; 'c' points to the ribbon rocking gear and bearing on the left; and 'd' points to the sprocket drum bearing at the bottom.</p> </div> <p>Main Unit of Recorder</p> <p>Fig. 10.1 Oiling Spots</p>

(To be continued to next page)

## 10. MAINTENANCE

(To be continued from previous page)

Maintenance Item	Procedure
Fuse	<p>For better maintenance, the replacement of fuse every two years is recommended.</p> <p>⚠ Turn OFF the switch and also the power to replace fuse.</p> <p>⚠ Use the recommended fuse by our company. (Fire prevention) Do not make a short circuit in the holder.</p> <p>Replacement Procedures:</p> <ol style="list-style-type: none"> <li>(1) Turn OFF the power at first, and turn off switch of the recorder.</li> <li>(2) Remove fuse with a minus-screw driver, since the fuse is set on the reverse side of the instrument (see Fig. 10.2)</li> <li>(3) Set a new fuse.</li> </ol> <div style="text-align: center;"> <p>Reverse side of recorder</p>  <p>Fig. 10.2 Set Position of Fuse</p> </div>

## 10. MAINTENANCE

Notes: Logging Print and Ribbon Life.

Using the ribbon over life then fiber will be scraped which cause fault on ribbon feeding and defect of the printer. Life of the ribbon will be shorter according to logging print times. Following is a table of logging print times and ribbon life to be referred. Check ribbon scrape regularly, replace the ribbon if found scrape or ravel on it in spite of ribbon life described in a table.

1. Logging or ribbon life: 100,000 letters

(1,200,000 dotting: 12 dotting per letter)

2. Logging print and ribbon life

Model	LOGGING PRINT INTERVAL / RIBBON LIFE											THE NUMBER OF LETTERS PER LOGGING (STANDARD)
	10M	20M	30M	1H	2H	3H	4H	6H	8H	12H	24H	
6CH RECORDER	11 DAYS	23 DAYS	34 DAYS	69 DAYS	90 DAYS	→	→	→	→	→	→	60 LETTERS
12CH RECORDER	5 DAYS	11 DAYS	17 DAYS	34 DAYS	69 DAYS	90 DAYS	→	→	→	→	→	120 LETTERS
24CH RECORDER	2 DAYS	5 DAYS	8 DAYS	17 DAYS	34 DAYS	52 DAYS	69 DAYS	90 DAYS	→	→	→	240 LETTERS
30CH RECORDER	2 DAYS	4 DAYS	6 DAYS	13 DAYS	27 DAYS	41 DAYS	55 DAYS	83 DAYS	90 DAYS	→	→	300 LETTERS

3. Ribbon life subject to be shorter than described in above according to the number of letters for scale, comment, list, alarm or logging print.

4. The longest ribbon life: 90 days (Recording cycle: 5,10 sec/CH)

45 days (Recording cycle: 2.5sec/CH)

## 10. MAINTENANCE

### 10.4 Replacement of Drive Cable

The printer of the recorder is connected with motor by using a drive cable.

The cable is covered with nylon. If this cover cracks or is peeled off, an increased recording error or abnormal printing can be caused. For keeping better recording quality, it is recommendable to replace the cable at intervals of 2 years.

#### (1) Pulling out the main unit:

- ① Depress the power switch to turn OFF power.
- ② Pull out the main unit holding the hand grip of drawer, until it stops at the point shown in the figure below while pushing down the unlocking lever.

Note: Pull out the main unit slowly holding it with your hands.




Fig 10.3 Pulling out the main unit

- ③ The printed-circuit board installed in a case of main unit is connected with a flat cable. Flip over the levers at both ends of the connector of the main unit for unlocking, and then, disconnect the flat cable.

Note: Disconnecting connector should be done at the connector of main unit side. Do not disconnect the connector of the printed-circuit board in the case. (For preventing damage of the printer CPU card)




Fig. 10.4 Disconnecting Flat Cable

## 10. MAINTENANCE

### (2) Replacement of drive cable:

- ① Remove the ribbon cassette from the printer.
- ② Loosen and remove the screw of the bracket securing a drive cable with a screw driver to remove the bracket of drive cable.
- ③ Loosen the screws on the adjusting flange of drive cable and pulley with an Allen wrench, and then, remove the pulley from the motor axis.




Fig. 10.5 Removing Drive Cable  
(Top Eye View)

- ④ Remove the drive cable from the guide bearing.
- ⑤ Push the small ball attached to one end of a new drive cable into the groove of pulley, and wind up the cable around the pulley by two turns.

- ⑥ Then, wind up the other end of cable around the pulley by five turns.




Fig. 10.6 Winding up Drive Cable with Pulley

- ⑦ Fix the drive cable with the pulley with adhesive tape to prevent the cable from looseness.
- ⑧ As shown the below figure, put the drive cable over the guide bearing, then insert the motor shaft into the pulley.




Fig. 10.7 Fitting Drive Cable  
(Top Eye View)

## 10. MAINTENANCE

- ⑨ Remove the adhesive tape attached the pulley temporarily. Fasten the screw set with the pulley with an Allen wrench, to fix the pulley with the motor shaft.

Note: The pulley has to be fixed with plate, 0.5 mm remotely from it.




Fig. 10.8 Fixing Pulley with Motor  
(A Lateral View)

- ⑩ Pull the drive cable to right and left several times, so that the wound drive cable can be firmly fit with the pulley.

- ⑪ Fix the adjusting flange of drive cable with the screws to the frame of the main unit, by adjusting it is being fixed parallel with the frame.




Fig. 10.9 Adjusting Flange of Drive Cable

- ⑫ Attach the adjusting flange of drive cable to the printer.
- ⑬ Move the printer to right and left to check that the drive cable moves smoothly.

### (3) Installing main unit:

- ① Connect the flat cable attached to the printed circuitboard with the connector at the main unit.
- ② Insert the main unit into the case until it stops.

## 11. CALIBRATION

### 11. CALIBRATION

Note: 1. Calibrate the recorder when there is a large error.  
For an accurate measuring, it is recommendable to calibrate the recorder for every year.

2. Calibration involves the following four tasks, and those adjustments of the item ② ~ ③ have to be done according to input mode.

- ① Pointer adjustment
- ② Range adjustment 1(mV, V, mA, thermocouple input)
- ③ Range adjustment 2(resistive temperature detective input)
- ④ Cold junction compensating adjustment of input terminal block (thermocouple input)

3. Do the calibration later than 30 minutes after turning on the power.

4. Checking the pointer position can be made according to the article '⑤ Checking Channel Data'.

5. During the calibration mode, no measurement and no analog printing can be done. Printing can be executed whenever the user mode is set.

#### ① Pointer Adjustment

Notes: 1. It is essential to calibrate channel each.

2. Do not move the pointer exceedingly towards both of zero side and span side.


If so, abnormal noise or unusual recording could be happened. Further, when returning to user mode, the "Error" mode is indicated, and it can be released by depressing **RUN/STOP** key.

◆ Depress **MODE** key to select 'MAN' mode in the unlocking state.

Depress **ENT** key and **<** key simultaneously for 10 seconds.

All the 6 indicator lamps are turned on, and the Pointer Adjustment Mode(**CAL. P**) is shown in the indicator. (Calibration Mode)

◆ Further, depress **ENT** key, then "00" is shown in the indicator (2) as follows;



"00" is indicated.

Fig. 11. 1 Indication of Pointer Adjustment

## 11. CALIBRATION

### <Zero side adjustment>

- ◆ Depress **PGM** key to show a indication of blinking "□□ □" in the indicator (2) and to left the pointer indicate zero point. Blinking

You can move to left depressing **▽** key and to right depressing **△** key.

Depress **ENT** key after setting the pointer with zero point of scale plate.

Print with a purple dot on the zero point of chart paper at that time, after checking that the plotting point matches with the zero point.

Notes: In the event that the zero point of scale plate does not match with the zero point of chart paper, position of the scale plate should be adjusted to match its zero point with that of the chart paper.

### <Span side adjustment>

- ◆ "□□ **S**" in the indicator (2) blinks, and the pointer indicates pan point, after Blinking

depressing **ENT** key in the steps of preceding article ◆.

Depress **ENT** key to print a purple dot on the span point of the chart paper after setting the pointer with span point according to the article ◆.

Note: 1. The pointer moves the same distance as determined for zero side adjustment.

2. Adjust the position of scale plate as zero point, since span point recording position of chart paper may be varied due to expansion and contraction of chart paper.

- ◆ Return to the state described in the article (1) after the last step of the article (4). Depress **MODE** key to indicate 'End-----' for finish of pointer adjustment, and then, depress **ENT** key to move to Auto Mode.

版	年	月	日	設計	承認	変更	事項	II	III	IV	V
I	5	9	25	山	細						



## 11. CALIBRATION

ex) Pointer adjustment:

C	A	L	P
---	---	---	---

0	0			-
---	---	--	--	---

      Indication pointer adjustment

PGM

C	A	L	P
---	---	---	---

0	0			0
---	---	--	--	---

      Matching with zero point  
Pointer indicates zero point regardless input.

(Match the pointer with zero point of the scale plate, operating 

▽
---

 key to move it to right and 

△
---

 key to move it to left.)

ENT      Setting zero point (The zero point is plotted at this time.)

C	A	L	P
---	---	---	---

0	0			S
---	---	--	--	---

      Matching with span point  
Pointer indicates span point regardless input.

(Match the pointer with span point of scale plate, operating 

▽
---

 key to move it to right and 

△
---

 key to move it to left.)

ENT      Setting span point (The span point is plotted at this time.)

C	A	L	P
---	---	---	---

0	0			-
---	---	--	--	---

      Indication of channel calibration.

Fig. 11.2 An Example of Pointer Adjustment

## 11. CALIBRATION

②Range Adjustment 1 (An adjustment is made in case of mV, V, mA, thermocouple input.)

- ◆ Select the voltage input point for calibration by a switch. The switch is located at the position front below right.  
Select "OFF" to input to the rear input terminal, or select "ON" to input to the front calibration terminal.

Note: The front calibration terminal is an optional function for the RM18G/N Multipoint Recorders.




Fig. 11.3 Input from Front Calibration Terminal (Option)

- ◆ Get into Calibration Mode through the steps just as the article ①-◆.

Depress **MODE** key to select 'Range Adjustment 1 Mode'.

At this time, in the indicator (2), "F" is indicated in case that the switch of front calibration terminal is being ON; "—" is indicated in case that switch is being OFF, or there is no front calibration terminal. And "F" is blinking at the right-end digit.

## 11. CALIBRATION




Fig. 11.4 Indication of Range Adjustment 1

- ◆ Depress **ENT** key once to indicate the blinking "□" in the indicator (2).  
The blinking "□□" is indicated in case of front calibration mode and is fixed.




Fig. 11.5 Indication of Input Channel No.  
(Range Adjustment 1)

- ◆ Select the impressed input channel operating **▽** **△** key in case of rear part input.
- ◆ In case of rear part input, the input wiring at the impressed input channel terminal selected by the step in the article ◆, has to be installed (see Fig. 11.6 shown below). In case of front calibration input, the wiring has to be installed using the attached plug with a lead wire according to Fig. 11.3.

## 11. CALIBRATION




Fig. 11.6 Wiring for Range Adjustment 1  
(Rear Part Input)

- ◆ Depress **PGM** key to indicate the input voltage in the indicator (1) and counter value of input in the indicator (2)

At this time, input voltage indicated in the indicator (1) in sequence, and depress **ENT** key at 30 seconds, after that.

For input of voltage, refer to Chart 11.1.

Note: Counter value of input would be about '0' count, in case of 0mV input, otherwise about 60000 counts.

Chart 11.1 Input Voltage (Range Adjustment 1)

Indicated Input Voltage	Input Voltage
V 0 0 0	0. 0 0 0 mV $\pm 2 \mu V$
V 0 1 0	1 0. 0 0 0 mV $\pm 2 \mu V$
V 0 1 5	1 5. 0 0 0 mV $\pm 2 \mu V$
V 0 2 0	2 0. 0 0 0 mV $\pm 2 \mu V$
V 0 3 0	3 0. 0 0 0 mV $\pm 5 \mu V$
V 0 3 5	3 5. 0 0 0 mV $\pm 5 \mu V$
V 0 4 5	4 5. 0 0 0 mV $\pm 5 \mu V$
V 0 5 5	5 5. 0 0 0 mV $\pm 5 \mu V$
V 0 7 0	7 0. 0 0 0 mV $\pm 5 \mu V$
V 2 0 0	2 0 0. 0 0 0 mV $\pm 1 0 \mu V$
V 5 5 V	5. 5 0 0 V $\pm 1 mV$

## 11. CALIBRATION

ex) Range adjustment 1




Fig. 11.7 An Example of Range Adjustment 1

Note: It takes about 30 seconds that input voltage by the voltage generator becomes stable. So, before depressing of **ENT** key, wait at least 30 seconds after voltage input.

## 11. CALIBRATION

### ③ Range Adjustment 2 (An adjustment is made in case of the resistive temperature detector input.)

Notes: In case of several input modes are to be made, range adjustment 2 should be made after range adjustment 1.

◆ Select the voltage input point by a switch for calibration like in the manner described in the article ①-◆.

◆ Enter into the Calibration Mode just as the manner described in the article ①-◆.

Depress **MODE** key to select Range Adjustment 2 Mode.

In the indicator (2) at this time, "F" is indicated in case that switch of front calibration terminal is being ON; "r" is indicated in case that switch is being OFF, or there is no front calibration terminal.

And "R" is blinking at the right-end digit.




Fig. 11.8 Indication of Range Adjustment 2

◆ Depress **ENT** key once to indicate the blinking "□" in the indicator (2), "□□" is indicated in case of the front calibration and is fixed.

◆ Select the impressed input channel by operating **▽** **△** key.

## 11. CALIBRATION

- ◆ In case the rear part input, install input wiring to the impressed input channel terminals selected as described in the article ◆ (see Fig. 11.9).

Note: Dispersion of resistance of each wire should be less than 6 mΩ.




Fig. 11.9 Wiring for Range Adjustment 2 (Rear Part Input)

- ◆ Depress **PGM** key to indicate the input voltage in the indicator (1) and counter value of input in the indicator (2).

At this time, input resistances corresponding to the voltages indicated in the indicator (1).

Before depressing **ENT** key, wait at least 30 seconds after input of resistance.

For input of resistance, refer to Chart 11.2.

The indication of each resistance input can be changed by operating **▽** **△** key.

Execute calibration by changing the resistance indication sequentially.

Chart 11.2 Input Resistance (Range Adjustment <2>)

Indicated Input Resistance	Input Resistance
r 0 1 0	1 0 . 0 0 0 Ω ± 5 m Ω
r 0 2 0	2 0 . 0 0 0 Ω ± 5 m Ω
r 0 5 0	5 0 . 0 0 0 Ω ± 5 m Ω
r 0 8 0	8 0 . 0 0 0 Ω ± 5 m Ω
r 1 0 0	1 0 0 . 0 0 0 Ω ± 5 m Ω
r 1 5 0	1 5 0 . 0 0 0 Ω ± 5 m Ω
r 3 0 0	3 0 0 . 0 0 0 Ω ± 5 m Ω

Notes: 1. It takes about 30 seconds that input resistance after changing input, becomes stable. So, before depressing of **ENT** key, wait at least 30 seconds after input of resistance.

2. Counter values are indicated within a range of 5000 ~ 50000.

## 11. CALIBRATION

### ④ Cold Junction Compensating Adjustment of Input Terminal Block


<An adjustment is made in case of thermocouple input.>

- Notes: 1. The cold junction compensating adjustment is made for each terminal block.  
For instance, in case of the 30-multipoint recorder, the 5 terminal blocks are adjusted in the same procedure as shown in Fig. 11.11.
2. For cold junction compensating adjustment, the common value for all terminal blocks are set.


◇ Get into the Calibration Mode according to the procedures of the article ①-◇.

Depress **MODE** key to select the Cold Junction Compensating Adjustment Mode.

Indicator(1)



Indicator(2)



Cold junction compensation  
adjustment

Fig. 11.10 Indication of Cold Junction Compensation Adjustment

HXP	RM18mmG0002E	96頁	版	年月日	設計	承認	變更	事項	II	IV
				95.9.25	出	日			III	V



## 11. CALIBRATION

◇ Operating   key to select the terminal block for calibration, after depressing  key.

Indicator (1)	Indicator (2)	
<input type="text" value="C"/> <input type="text" value="J"/> <input type="text" value="C"/> <input type="text"/>	<input type="text" value="1"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	CJC1 (Selection of the terminal blocks for channels 1 - 6)
<input type="text" value="C"/> <input type="text" value="J"/> <input type="text" value="C"/> <input type="text"/>	<input type="text" value="2"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	CJC2 (Selection of the terminal blocks for channels 7 - 12)
<input type="text" value="C"/> <input type="text" value="J"/> <input type="text" value="C"/> <input type="text"/>	<input type="text" value="3"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	CJC3 (Selection of the terminal blocks for channels 13 - 18)
<input type="text" value="C"/> <input type="text" value="J"/> <input type="text" value="C"/> <input type="text"/>	<input type="text" value="4"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	CJC4 (Selection of the terminal blocks for channels 19 - 24)
<input type="text" value="C"/> <input type="text" value="J"/> <input type="text" value="C"/> <input type="text"/>	<input type="text" value="5"/> <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/>	CJC5 (Selection of the terminal blocks for channels 25 - 30)

Fig. 11.11 Selection of Terminal Block (Cold Junction Compensating Adjustment)

## 11. CALIBRATION

◆ Connection of the cold junction compensating adjustment is made as per Fig. 11.12.




Fig. 11.12 Connection of Cold Junction Compensating Adjustment

Note: Before calibration, wait at least 5 minutes after the wiring, and putting a cover for the terminals.

- ◆ Check the thermocouple input beforehand, in the event that  $0.000 \text{ mV} \pm 2 \mu\text{V}$  is being impressed by the voltage generator.  
If the thermocouple input is  $0.0^\circ\text{C}$ , the calibration would not be needed.  
Since there is a difference in case of other than  $0.0^\circ\text{C}$ , compensate the difference.
- ◆ When ENT key is depressed in the state of (2), current temperature is indicated in the indicator (2).

Indicator (1)  
C J C

Indicator (2)  
2 4 . 5

ex) Selection of cold junction compensating adjustment CJCl  
Compensating value:  $24.5^\circ\text{C}$

Fig. 11.13 Indication of Cold Junction Compensating Adjustment

## 11. CALIBRATION

- ◆ Depress PGM key to change the indication the cold junction compensating adjustment value, and the value indicated in the indicator (2) is changed to the cold junction compensating adjustment value calculated at the article (5).

[Manipulation of key]

**Input digit**

Moving of Digit: Depress **ENT** key to move to right or **◀** to left.

Changing Value: Depress  or

ex)

In the event that thermocouple input is being  $-0.5^{\circ}\text{C}$ , and the normal temperature of room indicated in the indicator (2) is being  $24.5^{\circ}\text{C}$ ;  $25^{\circ}\text{C}$  of the difference is the value of cold junction compensating adjustment.

- ④ Depress ENT key at the state of right-end digit being blinking.
- ④ The value of cold junction compensating adjustment of other terminal block is changed to the value as inputted in the article (6).
- ④ Depress MODE key to select "CAL End", and depress ENT key to move to Auto Mode from Calibration Mode.
- ④ Check the data of each channel at normal mode.  
Do calibration again in case that the data is inaccuracy.

### ⑤ Checking Channel Data Designation

IV	V
----	---

IV	V
----	---

III	III
-----	-----

- 頃

海

夏

- 变

認

三

- 版 I

# 11. CALIBRATION

◆ Depress **MODE** key to change to the manual mode of user mode.

The checking scale of each channel can be made at the state of an input.

Each channel is set as shown below chart for actuation.

For changing channel, operate **▽** **△** key to select channel number for checking, and then check the scale.

Input	Range, Scale and Setting Alarm	CJC Using Value
Fixing of channel set in Art. ◆	Channel number range changed by operating <b>▽</b> <b>△</b> key.	Fixing of Channel set in Art. ◆

◆ For returning to normal, return the indication of indicator (2) to "normal" after getting into Calibration Mode in the manner just as the article ◆.


HXP	RM18mm	G0002E	1/2	頁	葉	版	年月日	設計	承認	變更	事項	II					IV	
						I	95.9.25	11 出 日	終 了							V		

12. TROUBLESHOOTING

12. TROUBLESHOOTING

12.1 Troubleshooting


(1) Troubles



## 12. TROUBLESHOOTING

(2) Flowcharts of countermeasure for trouble:


① Flowchart 1



版	年	月	日	設計	承認	變更	事項	II	III	IV	V
	I	年	5, 25	日	日						

## 12. TROUBLESHOOTING


② Flowchart 2





## 12. TROUBLESHOOTING


③ Flowchart 3



版	年	月	日	設計	承認	變更	事項	II	III	IV	V
I	95	9	25	11/11	細谷						

## 12. TROUBLESHOOTING

④ Flowchart 4



IV V

II III

項 更 事 變

承認 細 目

設計 日 月 年

95.9.25

版 I


業

頁 106

HXP<sub>RM18mm</sub>G0002E

## 12. TROUBLESHOOTING


⑤ Flowchart 5



版	年	月	日	設計	承認	變更	事項	II	IV	V
I	95	9	25	11/11	11/11			III		

## 12. TROUBLESHOOTING


⑥ Flowchart 6



HXP	RM18mnG0002E	1/28 頁	業	版	年	月	日	設計	承認	變更	事項	II	III	IV	V

## 12. TROUBLESHOOTING

⑦ Flowchart 7



HXP	RM18mnG0002E	107	頁	業	版	年月日設計	承認	變更	事項	II					IV	
					I	95.9.25	基	細部							V	

## 12. TROUBLESHOOTING

### 12.2 Self-diagnosis of Error

The recorder always diagnoses by itself the troubles described in Section 12.1. It shows error indication(refer to the articles (2) and (3) by its self-diagnosis function when something is wrong(an error arises).

(1) Self-diagnosing items:

Chart 12.1 A List of Self-diagnosing Items

Error No.	Diagnosing Items	Countermeasures
0 1	Something wrong about printer servo. The printer head could not move freely.	1)Set drive cable correctly. (Refer to Section 10.1.) 2)Set ribbon cassette properly. Refer to Section 6.2.) 3)Set connector of printer correctly. (Refer to the article (4) of Section 10.1.)
0 2	Zero point of printer is wrong. Zero point of printer cannot be detected.	
0 3	The position of printer ribbon is wrong. The position of printer ribbon cannot be detected.	
0 4	Marking of the printer CPU card is wrong. Selection of mark cannot be done.	
0 5	Disconnection between main CPU card and printer CPU card	Contact our salesman or shop where you purchased the recorder.
0 6	Command of printer CPU card is wrong.	
0 7	Recorder does not work.	Fit ADC card correctly.
0 8	ADC card is wrong.	
0 9		
1 0	Recorder does not work.	
1 1		
1 2	The calibrated value of ADC card is wrong.	
1 3		
1 4	Recorder does not work.	
1 5		
1 6	Nonvolatile memory of ADC card is wrong.	
1 7	Recorder does not work.	Set input terminal block correctly. (Refer to Chapter 5.)
1 8		
1 9	The calibrated value of the terminal block for channels 1 - 6 are wrong.	
2 0	The calibrated value of the terminal block for channels 7 - 12 are wrong.	
2 1	The calibrated value of the terminal block for channels 13 - 18 are wrong.	
2 2	The calibrated value of the terminal block for channels 19 - 24 are wrong.	
2 3	The calibrated value of the terminal block for channels 25 - 30 are wrong.	
2 4	Nonvolatile memory of terminal block of channels for 1 - 6 are wrong.	

## 12. TROUBLESHOOTING

Error No.	Diagnosing Items	Countermeasures
2 5	Nonvolatile memory of terminal block for channels 7 - 12 are wrong.	Set input terminal block correctly. (Refer to Chapter 5.)
2 6	Nonvolatile memory of terminal block for channels 13 - 18 are wrong.	
2 7	Nonvolatile memory of terminal block for channels 19 - 24 are wrong.	
2 8	Nonvolatile memory of terminal block for channels 25 - 30 are wrong.	
2 9	Recorder does not work.	
3 0	Recorder does not work.	
3 1		
3 2		
3 3		
3 4		
3 5		
3 6		
3 7	The designated calibration value of Multipoint Recorder is wrong.	Contact our salesman or shop where you purchased the recorder.
3 8	Writing to nonvolatile memory is wrong.	
3 9	The data of nonvolatile memory is wrong.	
4 0	The front calibrated terminal is wrong.	
4 1	Clock memory is wrong.	
4 2	Watch dog timer is wrong	
4 3	Something wrong is software	

### (2) Error message:

- Error message is indicated only when the display indicates Auto Mode.
- When multiple errors arise, the error number is indicated automatically in sequence.

Note: The indication of alarm ON is not made, while indication of error.




Fig. 12.1 Indication of Error No. 1

## 12. TROUBLESHOOTING

### (3) Error Output (FAIL)

When an error is occurred, FAIL output is made as follows:

#### i) In case of standard specification.

When an error is occurred, the error output (FAIL) will become 'ON' state.

#### ii) In case of Designation of power off (Option):

When an error is occurred, the error output (FAIL) will become 'OFF' state.

At Power Off      In Normal Operation      At Occurrence of Error




Fig. 12.2 Error Output (FAIL)



### 13. SPECIFICATIONS

### 13. SPECIFICATIONS

#### Standard Specifications

#### ● Input Signals

DC voltage: 4mV range or over, Max 20V DC

Thermocouple: K, T, J, E, B, S, R, G, C, N,

PR40-20, PLII, Au-Fe, U, L

Resistive temperature: Pt100, JPt100, Pt50  
detector Cu 10 Ω at 0°C

Cu 10 Ω at 25°C

DC current : 4~20mA DC

Electric : 1μS/cm~20000μS/cm

conductivity (Option)

#### ● Performance and characteristics

Indication accuracy rating: ±0.5% or less

Dead band : 0.2% or less

Input resistance: mV, TC(without burn-out)

; 10MΩ or over

mV, TC(with burn-out);

200KΩ or over

V ; 1MΩ or over

mA ; 100Ω (external

shunt resistance)

Signal source resistance:

mV, TC(without burn-out); 10KΩ or less

mV, TC(with burn-out): 200Ω or less

V : 1KΩ or less

Resistive temperature detector

: 10Ω or less (per line)

Normal mode rejection ratio:

60dB or more (at 50/60±0.5Hz)

common mode rejection ratio:

140dB or more (at 50/60±0.5Hz)

Isolation resistance :

0.5kV AC 20MΩ or more between  
each terminal and ground

Dielectric strength : Between power terminal  
and ground: 2KV AC for one minute

Between input terminal

and ground: 0.5kV AC for one minute

Vibration resistance: 10 ~ 60Hz 1m/s<sup>2</sup> or less

Shock resistance : 2m/s<sup>2</sup> or less

Clock accuracy : ± 5 0 p p m

Feeding speed accuracy : ± 0 . 1 %  
of chart paper

#### ● Structure

Case structure : Dust-resistant structure

Installation : Encased in vertical panel,  
Permissible inclination up  
to 30° back

Material : Case ; steel

Door frame ; Aluminum die  
casting

Paint : Case ; Metallic silver

Door frame ; Black(standard)

#### ● Power supply

Supply voltage : 8 5 ~ 2 6 4 V A C

Wave-frequency : 4 5 ~ 6 5 H z

#### ● Normal operating range

Operation temperature : - 5 ~ 5 0 ° C

Operation humidity: 3 5 ~ 8 5 % R H

#### ● Alarm (relay output: Option)

Alarm modes : 6 modes per channel (H, HH, L  
LL, RH, RL)

Number of drives: 2 relay drives per setting

Contact : 250V AC 3A Max(resistive load)

Rating : 125V DC 0.5A Max(resistive load)

: 30V DC 3A Max(resistive load)

Hysteresis amplitude : 0 . 5 ± 0 . 2 %

Setting accuracy : ± 0 . 5 %

### 13. SPECIFICATIONS

#### Multipoint Recorder Specifications

Mode	Item	Multipoint Recorder Specifications
Input	Number of measuring	6, 12, 24, 30,
	Measuring cycle	2.5 / 5 / 10 sec/CH
Recording Printing	Recording	5 kinds of mark (• ◦ + √ ×)
	Printing	Wire dot printing (6-color ribbon)
	Effective recording width	180 mm
	90% step response or less	—
	Recording cycle	2.5 / 5 / 10 sec/CH
	Chart paper	23m(length)× 210mm (width) Folding width : 60mm
	Paper feeding speed	1 ~ 1 8 0 0 mm/h
	Recording color	(•)(◦)(+)(√)(×) No. 1, 7, 13, 19, 25 (Purple) No. 2, 8, 14, 20, 26 (Red) No. 3, 9, 15, 21, 27 (Black) No. 4, 10, 16, 22, 28 (Green) No. 5, 11, 17, 23, 29 (Blue) No. 6, 12, 18, 24, 30 (Brown)
	Print color	Purple (Red)
Outside dimension (W x H x D) (Std.)		G type 288 x 288 x 340 N type 288 x 322 x 340
Weight (Std.)		15.0 kg or less
Maximum power consumption		4 5 V A

### 13. SPECIFICATIONS

#### Standard Functions

Function	Description
Analog indication	The measured value is indicated by the scale plate and the pointer. In the manual mode, the recorder can be used as the 1-point recorder with 0.5 sec. cycle.
Analog recording	Analog recording can be made with 5-mark and 6-color ink ribbon.
Unit of indication	Unit of the measured value is indicated on the scale plate.
Digital indication	Channel number, measured value, date, paper feeding speed, alarm setting, etc. are indicated in the indicators (1) and (2).
Interval log print	The measured value and its unit for each channel are printed at set intervals. Either one of printing modes such as "Forced paper feed" and "Synchronizing paper feed".
Date print	Date is printing at the designated time.
List print	To the print type of sensor each channel, measuring range, unit, alarm setting, date, time, paper feeding speed, scale value, and setting condition of interval log.
Random setting function	Setting of, paper feeding speed, alarm point, interval of interval log print, date, and time can be made.
Backup memory	Clock is protected with lithium cell built in. Life-time of the cell is about 10 years (total non conducting-period of the instrument is 5 years). The set data are protected with non-volatile memory.
Key lock	If you don't use key for more than 5 minutes in a user mode, the key would be locked automatically.
Alarm	Six types of alarm mode can be set for one channel.
Paper feeding speed	Two types of paper feeding speed(1st and 2nd)can be selected for setting.
Clock	Year, month, day, hour, and minute are indicated. Year is set with the dominical year, and for a leap year, the calendar is adjusted automatically.
Self-diagnosis	The indication of error is made when any one errors arises.

## Optional Functions

Function	Description
Burn-out	To deflect over either one of 0% side or 100% side, in designating of input disconnection. Setting UP and DOWN for each channel can be made. (mV, thermocouple input)
Zone recording (Recording of track)	Segregating recording of track, by designating recording zone for each channel can be done.
Partial compression and enlargement	Partial compression and enlargement in the same range can be done.
Scale print	The scale values of zero point and span point of each channel are printed.
Alarm print	When an alarm arises, alarm-on time, alarm-on channel, alarm setting number, and alarm mode are printed in purple color.
Alarm recovery print	When an alarm is recovered, the time of recovery, the recovered channel, alarm setting number, and alarm mode are printed in purple color.
Front calibration terminal	The designated front calibration of voltage can be made by changing input.
DE wire connection input	To execute the compensating temperature, taking in, the inside temperature of outside compensating box by thermocouple input of the set channel.
DH wire connection input	To execute the compensating temperature, taking in, the inside temperature of outside compensating box by the voltage wire (copper wire) of the set channel.
Calculation of channels	The sum of channels or difference between channels are communicated to the designated channel and recorded.
Temperature difference input	The actual temperature after subtracting the reference temperature of reference channel is designated and recorded.
Scaling	Input of standard signal, etc. is converted into actual scale and recorded.
Display OFF	To turn off the designated value in the display through Auto Mode.
New alarm	New alarm channel is output in one-shot relay.
Changing range (two ranges)	To change two types of range through DI signal.
Alarm hysteresis range	The hysteresis range can be set optionally. (Standard : 0.5% FS)

### 13. SPECIFICATIONS

#### Special Optional Functions

##### ●Remote Functions by DI

Function	Description
Chart Start/Stop	Setting contact "ON" to start, and "OFF" to stop.
Changing feeding speed of chart paper	Changing contact to "ON" to set 1st position, and to "OFF" for 2nd position.
Chart feeding pulse	Feeding amount at outside of chart.
Changing chart feeding speed INT/EXT	Changing contact "OFF" to internal speed changing mode, and "ON" to external speed changing mode.
Comment print	The set characters are printed (up to 16 characters per line).
Outside log print	Setting contact "ON" to print.
Outside date print	Setting contact "ON" to print.
Integrating input	To integrate the input with a certain amount in proportion to the numbers of setting contact "ON"
Reset of integration	To reset the integrated value.
Changing range	To change the range setting contact "ON" to 'Range 1', "OFF" to 'Range 2'.
New alarm reset	To execute new alarm reset, setting contact "ON".

##### ●Inside Alarm : Number of relay : 8

##### ●Optional Communication Unit :

Function	Description
Communication unit	RS-232C
	RS-422A
	ARCNET®

ARCNET® is the trade mark of Data Point Inc., in U.S.A.

HXP	RM18mmG0002E	118 頁		版	年月日	設計	承認	變更	事項	II					IV
		業													
		I	95.9.25	年月日	設計	承認				III					V

HXP	RM18mmG0002E	118 頁		版	年月日	設計	承認	變更	事項	II					IV
		業													
		I	95.9.25	年月日	設計	承認				III					V

HXP	RM18mmG0002E	118 頁		版	年月日	設計	承認	變更	事項	II					IV
		業													
		I	95.9.25	年月日	設計	承認				III					V

# APPENDIXES

(Technical Terms)

normal mode rejection ratio

Ratio for voltage in normal mode (differential input voltage) versus an increase of its signal.

It is represented by decibel (dB).

precision

Means a synthetic fineness --- the accuracy, and minuteness of measurement by an instrument.

RS-232C

One of the standard specifications for serial communication assigned by the EIA (Electronic Industry Association -U.S.A.)

RS-422A

One of the standard specifications for serial communication assigned by the EIA (Electronic Industry Association -U.S.A.)

shunt resistance

Resistor to be set with terminal block for converting the input electric current into signal voltage.

sprocket drum

Chart paper feeding cylinder with gear teeth

thermocouple

Thermo sensor consists of a couple of the different materials that generate electromotive force by the thermoelectric effect at the junction.

warming-up time

After turning on the power of an instrument, it is the time required to meet all of its facilities with its rating.

watch dog timer function

Monitoring function of CPU that monitors whether CPU finishes a work within a certain period of time, and if not, determines that CPU is abnormal.

版	年	月	日	設	計	承	認	項	事	更	変	II	III	IV	V
I	95	9	25	11	11	11	11								
HXP RM18mg0002E															
1/9 頁															

## APPENDIXES

### Appendix 2. A Cross Reference List of Display Indication

The indicators (1) and (2) notate alphabet for its indication, because of 7 segments of LED, so that refer to the cross reference list shown below.

Note : There is no distinction between a capital letter and small letter.


A	B	C	D	E	F	G	H	I	J	K	L	M	N
O	P	Q	R	S	T	U	V	W	X	Y	Z	γ	



# APPENDIXES


## Appendix 3. Display

### (1) User Mode:



# APPENDIXES

## (2) Calibration Mode:



Note: All references in this flowchart mean Chapter 11.

HXP <sub>RM18mnG0002E</sub>	頁	122	版	年月日	設計	承認	變更	事項	II	III	IV	V